



FAFO Flight Controller

Connectors

Buzzer



I2C




LED




Camera




VTX




Currents




Power




UARTS




Battery




SBUS Inverter




USB C




Signal



LED Stat




SD Card




Power Supply


Decoupling Cap



5V Switching reg




3.3V reg




Sensors



Baro



Gyro



OSD



Sheet: /
File: Flight Controller.kicad_sch

Title:

Size: A3 Date:
KiCad E.D.A. eeschema 7.0.10

Rev:
Id: 1/1