

## AI xiaozhi Instructions

Preparation: a data cable is powered on and a 3.5mm wired audio output is produced

- 1、Connect the data cable to power
- 2、Follow the prompts on the device screen to connect to Xiao Zhi's hotspot (named as the prompts on the screen). After connection, you will usually jump directly to the browser networking interface. However, some phones cannot jump directly, so you can open the mobile browser and enter the url: <http://192.168.4.1>



- 3、Enter the WIFI name and password to connect to the network, or select one from the WIFI scanned below



10:17 192.168.4.1

### WiFi 配置

中文

**已保存的 WiFi**

- viewe
- CloudZao
- 依慧科---1

**新的 WiFi**

SSID: 1、输入WIFI名称


密码: 2、输入WIFI密码

连接 3

从下面列表选择 2.4G WiFi:

- ChinaNet-mYRR (-61 dBm)
- 聚强晶体 (-64 dBm)
- ChinaNet-Xt6M (-67 dBm)
- ChinaNet-XWsM (-69 dBm)
- viewe (-70 dBm)


4、After the network is connected, use the browser to access [xiaozhi.me](http://xiaozhi.me) for login and click the console to activate the device. However, you need to register an account before clicking the console. Log in and click the console after successful registration



5、Click Add device and enter the first line of numbers prompted on the device screen to add



6、Enter the verification code of the added device to confirm that the creation is successful (the string of numbers on the device screen is the verification code). Wait for the device to be created and you can chat



VIEWE TECH