

**FEITIAN**

# FeiTian UID PC Tool



V1.0

## Revision History:

Date	Revision	Description
September. 2015	V1.0	Release of the first version

## Contents

Chapter 1. Select bR500.....	4
Chapter 2. Connect.....	5
Chapter 3. About the card reader's flash.....	6
Chapter 4. About the card reader's UID.....	7

## Chapter 1. Select bR500

Select bR500 from the list in the drop-down box.




Figure 1

## Chapter 2. Connect

Click the Connect button.

The connect state on the bottom.

The GetSerialNo button for getting the serial number.




Figure 2

## Chapter 3. About the card reader's flash

The Read Flash button for reading the card reader's flash.

The Write Flash button for writing the card reader's flash.

The Save Data button for saving the Flash edit box's data as a document.

The Load Data button for loading the document into the Flash edit box.




Figure 3

## Chapter 4. About the card reader's UID

The Read UID button for reading the card reader's UID.

The Generate UID button for generating the card reader's UID.

The Erase UID button for erasing the card reader's UID.

The Seed edit box's data is used for generating and erasing the card reader's UID.




Figure 4

Figure 1.....	4
Figure 2.....	5

Figure 3.....6

Figure 4.....7