



**TASHA**

All Your Kitchen Needs

# User Manual: Appliance

Prepared by:  
TASHA - The Home Brand

Copyright 2019 

---

# FAQs

*Some commonly asked questions :*

## **How can I use 'broil' setting?**

Broiling is a setting used to do top browning. Always monitor the food on the "Broil" setting to ensure that you are not over cooking. We suggest using the timer as food can burn quickly on this setting.

When broiling, turn food over for even cooking. Food should not be placed directly on the wire rack. When broiling, some smoke is likely to occur. Removing excess fat prior to broiling can reduce this.

---

# FAQs

*Some commonly asked questions :*

**Do I have to preheat the microwave when I use it to reheat?**

No need to preheat the microwave if you are just using it for reheating purposes.

You only need to preheat the microwave if you are doing convection cooking.

---

# FAQs

*Some commonly asked questions :*

**How do I know if the temperature I set to preheat the oven have reached?**

An indicator light above the temperature selector will come on, once the temperature has reached, the indicator light will go off.

This means you can place the food into the oven for cooking.

---

# FAQs

*Some commonly asked questions :*

**Will the toaster get too hot or burn my toast if I use it several times in a row?**

The toaster comes with sensor browning control to toast successively several slices of bread with a constant result keeping the same temperature setting.

It has been tested in our labs that there'll be no burnt toasts

---

# Cleaning Guide

*Here is how to get the best of your refrigeration unit*

- Spray the cloth and wipe down the surface of the appliance.
- If you're cleaning an appliance with a removable part for catching crumbs or other waste food, remove it and clean it thoroughly.
- For items like toasters (which have a tendency to accumulate debris), shake them out over the bin. Do not get the heating elements of the toaster wet.
- Dislodge anything in hard to reach places using a dry toothbrush.

# Disposal Guide

Many appliances that no longer work can still be used for scrap metal. A process is completed that removes any harmful elements and iron from the appliance, and then the body or case can be re-used. Construction companies can often use these appliances and re-purpose them for various uses.

This is another good option for recycling appliances. It is always advised to try and donate any appliances that are still working to charities. For those that are not in working order, donating them for scrap metal is definitely a good alternative