




8500 is equivalent to 6510.
7501 is equivalent to 8501.

Solderjumper legend:
A = 6510
B = 6510T
C = 8501

For 6510, headers are at J1 pins 1-20 and 23-42.
For 6510T and 8501, headers are at J1 pins 2-21 and 22-41.
For 8502, headers are at J4, and jumpers don't matter.



Only needed for 8501
Need to solder the 6502 directly and/or use headers without the plastic piece in order for the module to fit in a Plus4 under the keyboard. C16 on the other hand, has plenty of height.



For *65C02 support

Open for W65C02
Using a *65C02 will result in reduced software compatibility due to CPU bugs fixed and undocumented opcodes altered, which are exploited by some software/games/demos.

