


LEFT IDLER

WWW.VORONDESIGN.COM

ASSEMBLY AID



This bolt is used to align components and will be removed in a later step.



M5x40 SHCS


F695 Bearing

M5 Shim




LEFT IDLER


WWW.VORONDESIGN.COM





ASSEMBLY AID

This bolt is used to align components and will be removed in a later step.







CHECK YOUR WORK

Compare your assembled parts to the graphics shown here. Pay attention to the features highlighted by the circles.