



## How to Connect?

1. After writing OS, insert the micro SD card to Raspberry Pi.
2. Install 4 brass standoffs.




3. Connect the ribbon cable.

**Note:** Pay attention to the blue bar on the cable when connecting.



4. Fix the Raspberry Pi with 4 screws and then connect the ribbon cable. Then install the stands with 2 screws.



5. Connect the power supply and wait a few seconds, the screen will display.

### If the screen doesn't display normally with Raspberry Pi OS

Open **boot/config.txt** on Raspberry Pi or use a computer to open this file in the micro SD card.

Modify **dtoverlay=vc4-kms-v3d** to **dtoverlay=vc4-fkms-v3d** or **#dtoverlay=vc4-kms-v3d**

Save the file and then reboot the Raspberry Pi.

**Having problems?** Download the latest tutorial and troubleshooting: <http://freenove.com/fnk0078>  
Need further help? Contact our technical support by email: [support@freenove.com](mailto:support@freenove.com)