
FSL Community BSP Release Notes Documentation

Release 2.4 (Draft document)

FSL Community BSP Team

Feb 26, 2018

CONTENTS

1	Defining the FSL Community BSP	2
1.1	Motivation	2
1.2	What the FSL Community BSP is not	2
1.3	What you can expect	3
1.4	What the community expects from you	3
2	Upstreaming	4
2.1	Main branch names	4
2.2	Upstream cycle	4
3	The differences between FSL Community BSP and Freescale Official Release	6
3.1	Freescale Official Release	6
3.2	FSL Community BSP	6
4	FSL Community BSP Scope	8
4.1	Meta-freescale	8
4.2	License	9
4.2.1	End User License Agreement (EULA)	9
4.3	Kernel Release Notes	9
4.4	Different Product SoC Families	9
4.5	Supported Board List	10
4.5.1	Machine Maintainers	12
5	Software Architecture	16
5.1	SoC Hierarchy	16
5.2	Linux Kernel	16
5.2.1	Default Linux Providers	17
5.3	Bootloaders	19
5.4	User Space Packages	21
5.4.1	Freescale User Space Packages	21
5.5	PackageGroups and Images	24
5.5.1	PACKAGEGROUPS	25
5.5.2	Images	25
5.5.3	Distros	26
6	Test results	27

7	Acknowledgements	28
7.1	Rocko Source Code	28
8	Known Issues	29

This document is the release notes for the FSL Community BSP 2.4 (Draft document), which is the result of a community effort to improve Freescale's SoC support for OpenEmbedded and Yocto Project.

Warning: This document is still in **draft** form and *shouldn't be considered finished*. In case you wish to contribute with suggestions, fixes or comments, then please get in touch through the [meta-freescale](#) mailing list.

This document is released under Creative Commons 4.0 (CC BY-SA 4.0)

If you want to make part of FSL Community BSP access <http://freescale.github.io> and find links to this document, how to contribute, and how to download both the source code and several pre-built images.

DEFINING THE FSL COMMUNITY BSP

The FSL Community BSP is a community-driven project to provide and maintain Board Support Package (BSP) metadata layers for use in OpenEmbedded and Yocto Project with Freescale's SoCs.

The FSL Community BSP follows Yocto Project's *release schedule* and *branch naming* (since release 1.3, denzil).

See the [Yocto Project Release](#) for details on the Yocto Project.

1.1 Motivation

The FSL Community BSP started with the goal of easing the use of OpenEmbedded and Yocto Project with Freescale's SoCs and providing an example of how to assemble an easy-to-use platform as the basis for future products.

The FSL Community BSP provides:

- common environment configuration;
- multiple download layers with the use of [repo](#);
- common [location](#) for discussing Freescale SoCs, kernels, bootloaders, user space packages, (BSP in general), bugs, how-tos, and so on

1.2 What the FSL Community BSP is not

The FSL Community BSP does not have a paid support team. The members of this community have full-time jobs and work on the project in their spare time. Most of them are working with Freescale SoCs in their full-time job, so it means some of them can provide paid support if requested.

The provided source code is not intended to be a product in itself. It is a reference platform for people to build products with. Because of this, plan to have a development and test cycle for your product if you decide to base it on the FSL Community BSP.

The project is community-driven work, and it is NOT an official Freescale support channel.

1.3 What you can expect

- You can expect help when you post a question, but please be patient. Wait for at least two days for a response. Most of the time, people do reply when they know an answer or have advice to offer. If you don't receive a reply, then it may be due to no one in the community having an adequate response.
- The stable branch is supported for six months after the release date (following the Yocto Project's release schedule);
- The upstreaming takes place as quickly as possible and any needed adjustment is going to be made accordingly.

1.4 What the community expects from you

The community does expect that you contribute back by:

- replying when you know the answer to a question in the mailing list;
- reviewing the patches sent to mailing list;
- testing new patches that affect you directly or indirectly;
- reporting bugs you may find;
- upstreaming bug fixes;
- upstreaming features that may be good for the community.

UPSTREAMING

The FSL Community BSP provides test images and demos in addition to the base BSP for Freescale reference boards and third-party boards. In addition to the BSP, a Linux-based operating system typically requires several other packages, such as ssh client/server, window managers, applications, and so on. These packages are not part of the BSP. In other words, the FSL Community BSP is used with applications, tools and metadata from other projects, such as OpenEmbedded and Poky.

The FSL Community BSP always offers a stable version and a development version. You may face errors that are not caused by FSL Community BSP's layers but instead by OpenEmbedded's or Poky's metadata. In this case, the error must be fixed in its layer.

The following image shows the upstream levels:

2.1 Main branch names

- **master-next**: this branch is used to keep the patches to be built by the autobuilder for the very first test build. Do not expect to have a clear merging schedule, or to have a stable project when working with the master-next branch;
- **master**: this is the branch where development takes place. Any new feature or bug fix must be merged here first. This is the development of the next stable branch;
- **rocko**: the latest stable branch. This branch only accepts bug fixes, and is supported for 6 months after the release date.

There are other branches available, and they are the previous stable branches. They are kept online for users' convenience, and you should not expect backports or bug fixes.

2.2 Upstream cycle

In addition to the normal Yocto Project upstream process, there is also a BSP upstream cycle.

The BSP upstream cycle starts just after a Freescale Official Release is published in git.freescale.com. The patches to adapt the recipes from **meta-fsl-bsp-release** are sent out for review to the **meta-freescale** mailing list and are merged in the **meta-freescale**, **meta-freescale-3rdparty** or **meta-freescale-distro** layers or upstreamed to Yocto Project accordingly.

A more detailed step-by-step process is shown below:

1. New Freescale Official Release is published;
2. The patches are sent to **meta-freescale**;
3. After the review process, the patches are merged in the proper layer's *master-next* branch;
4. Source code is built by the autobuilder;
5. After one week in *master-next*, it is merged in *master*;
6. Freescale internally bases the next Freescale Official Release from the community source code;
7. Back to step 1.

The result is that Freescale uses the FSL Community BSP source code with its bug fixes, improvements, and any new features to create the *next* Freescale Official Release.

Freescale uses the latest stable branch from Yocto Project to base the *next* Freescale Official Release. When this release is published, it is rebased and reworked to be merged in the current development branch.

THE DIFFERENCES BETWEEN FSL COMMUNITY BSP AND FREESCALE OFFICIAL RELEASE

The goal for each project is different. See below for the main points of divergence.

3.1 Freescale Official Release

The Freescale Official Release is intended to provide a static base for Freescale to test and validate the BSP modules with Freescale evaluation boards, and it is developed internally by Freescale. The set of supported boards vary from release to release and is listed in the Freescale Official Release notes for the specific version. The release points to a static revision of every included layer. Therefore, the release does not receive updates and bug fixes.

3.2 FSL Community BSP

The FSL Community BSP is a reference system that can be used as a base for products and is an open project that accepts contributions from the community. It supports a wide range of boards which range from Freescale evaluation boards (**meta-freescale** layer) to third-party boards (**meta-freescale-3rdparty**). The release is a “*moving target*”, so there are updates on top of the released source code, such as the addition of new features and bug fixes.

Table 1: Comparative between Freescale Official Release and FSL Community BSP

	Freescale Official Release	FSL Community BSP
Intended use	Reference system for BSP modules test and validation on Freescale Reference Boards	Reference system for use as base for any project for all supported boards
Code	Static. Only include any bug fixes on the upcoming release	Updates. Receives bug fixes and has security issues fixed often
Contribution	Indirect contribution via FSL Community BSP. After revision, contribution may be merged in upcoming release	Open, everyone is welcome to contribute to the project
Board Support	Limited, as it supports just the Freescale evaluation boards listed in the Release Notes	Extended, as it supports both Freescale evaluation boards and 3rd party boards. See Supported Board List
Yocto Project Compatible	No	Yes
Support	i.MX Community	meta-freescale
Repository	git.freescale.com	github.com/Freescale

FSL COMMUNITY BSP SCOPE

The scope of the FSL Community BSP includes the meta layers:

- **meta-freescale**: provides the base support and Freescale ARM and PPC reference boards;
- **meta-freescale-3rdparty**: provides support for 3rd party and partner boards;
- **meta-freescale-distro**: provides distros support, images recipes, demo recipes, and package-groups used to ease the development with Yocto Project.
- **Documentation**: provides the source code for FSL Community BSP Release Notes (RN) and User Guide (UG).

4.1 Meta-freescale

Since the Yocto Project release 2.2 (Morty) the FSL Community BSP changed the meta layers names. You can see the announcement [here](#).

The following table show the renaming upgrade path:

Krogoth	Morty
meta-fsl-arm	meta-freescale
meta-fsl-ppc	meta-freescale
meta-fsl-arm-extra	meta-freescale-3rdparty
meta-fsl-demos	meta-freescale-distros

The **meta-fsl-arm** and **meta-fsl-ppc** meta layers are deprecated. The last release for these meta layers is **krogoth**. Do not expect any update to the layer other than critical bug-fixes. **Meta-fsl-arm** and **meta-fsl-ppc** must be replaced by **meta-freescale**.

The **meta-freescale** meta layer goal is to integrate the ARM and PPC SoC based source code from Freescale, it includes **i.MX**, **Vybrid**, **QorIQ** and **Layerscape** BSPs.

The **meta-fsl-arm-extra** now is **meta-freescale-3rdparty**, any local copy should work as there is a mirror set.

The **meta-fsl-demos** now is **meta-freescale-distros**, any local copy should work as there is a mirror set.

4.2 License

The FSL Community BSP is a project with the same licensing of most Yocto Project layers. It means the recipe file is under a certain license, and the source code used by that recipe is under another certain license (being it equal or not).

Most of FSL Community BSP's metadata is under MIT license, however the extensive and accurate list of package's license provided by the Yocto Project's metadata can be generated with few commands, for detailed information on how license is handled by Yocto Project see the [Reference Manual](#).

4.2.1 End User License Agreement (EULA)

Freescall releases basically two kind of packages, the open sourced packages use regular open source licenses (GPLv2 for example).

The close sourced packages are released under the Freescale License (known as EULA). Each package has a copy of EULA inside itself and a copy of the EULA text is also included inside **meta-freescale** root dir (`sources/meta-freescale/EULA`).

The FSL Community BSP handles the EULA acceptance by prompting user to read and accept EULA text at the very first environment setup. It is user's duty to read and understand it before accepting it. After it is accepted the first time, it is assumed accepted in any other build.

4.3 Kernel Release Notes

The FSL Community BSP includes support for several kernel providers. Each machine may have a different Linux Kernel provider.

The FSL Community BSP is not responsible for the content of those kernels. Although we *as community* should feel empowered to submit bug fixes and new features for those projects.

See the respective Linux Kernel provider for your machine in section [Linux Kernel](#).

4.4 Different Product SoC Families

Currently, the FSL Community BSP includes the following Product SoC Families:

- **i.MX Application Processors (imx):** Regarding the [i.MX Freescale Page](#): *i.MX applications processors are multicore ARM®-based solutions for multimedia and display applications with scalability, high performance, and low power capabilities.*
- **Vybrid Controller Solutions based on ARM® Cores (vybrid):** Regarding the [Vybrid Freescale Page](#): *Vybrid controller solutions are built on an asymmetrical-multiprocessing architecture using ARM® cores as the anchor for the platform, and are ideal for many industrial applications.*

- **Layerscape Architecture (ls):** Regarding the [Layerscape Freescale Page](#): *delivers unprecedented efficiency and scale for the smarter, more capable networks of tomorrow.*

Freescale groups a set of SoCs which target different markets in product families. Those are grouped according to their SoC features and internal hardware capabilities.

The Yocto Project's tools have the required capabilities to differentiate the architectures and BSP components for the different SoC families. In this perspective, the FSL Community BSP can support a wide range of architectures and product lines which go across several markets.

For the FSL Community BSP, the different SoCs, from all product lines manufactured by Freescale, can be seen as different machines, thus easing the use of same architecture across different markets.

4.5 Supported Board List

Please, see the next table for the complete supported board list.

Table 1: Supported machines in FSL Community BSP

Machine	Name	SoC	Layer
apalis-imx6	Toradex Apalis iMX6Q/D	i.MX6Q	meta-freescale-3rdparty
cfa10036	Crystalfontz CFA-10036	i.MX28	meta-freescale-3rdparty
cfa10037	Crystalfontz CFA-10037	i.MX28	meta-freescale-3rdparty
cfa10049	Crystalfontz CFA-10049	i.MX28	meta-freescale-3rdparty
cfa10055	Crystalfontz CFA-10055	i.MX28	meta-freescale-3rdparty
cfa10056	Crystalfontz CFA-10056	i.MX28	meta-freescale-3rdparty
cfa10057	Crystalfontz CFA-10057	i.MX28	meta-freescale-3rdparty
cfa10058	Crystalfontz CFA-10058	i.MX28	meta-freescale-3rdparty
cgtqmx6	Congatec QMX6 Evaluation board	i.MX6 Q/DL	meta-freescale-3rdparty
cm-fx6	CompuLab CM-FX6	i.MX6 Q/DL	meta-freescale-3rdparty
colibri-imx6	Toradex Colibri iMX6DL/S	i.MX6DL	meta-freescale-3rdparty
colibri-imx7	Toradex Colibri iMX7D/S	i.MX 7Dual / i.MX 7Solo	meta-freescale-3rdparty
colibri-vf	Toradex Colibri VF50/VF61	VF500/VF610	meta-freescale-3rdparty
cubox-i	SolidRun CuBox-i and HummingBoard	i.MX6 Q/DL	meta-freescale-3rdparty
imx233-olinuxino-maxi	OLIMEX iMX233-OLinuXino-Maxi	i.MX23	meta-freescale-3rdparty
imx233-olinuxino-micro	OLIMEX iMX233-OLinuXino-Micro	i.MX23	meta-freescale-3rdparty
imx233-olinuxino-mini	OLIMEX iMX233-OLinuXino-Mini	i.MX23	meta-freescale-3rdparty
imx233-olinuxino-nano	OLIMEX iMX233-OLinuXino-Nano	i.MX23	meta-freescale-3rdparty
imx23evk	NXP i.MX23 Evaluation Kit	i.MX23	meta-freescale
imx25pdk	NXP i.MX25 Evaluation Kit	i.MX25	meta-freescale
imx28evk	NXP i.MX28 Evaluation Kit	i.MX28	meta-freescale

Continued on next page

Table 1 – continued from previous page

Machine	Name	SoC	Layer
imx51evk	NXP i.MX51 Evaluation Kit	i.MX51	meta-freescale
imx53ard	NXP i.MX53 SABRE Automotive Board	i.MX53	meta-freescale
imx53qsb	NXP i.MX53 Quick Start Board	i.MX53	meta-freescale
imx6dl-riotboard	RIoTboard	i.MX6S	meta-freescale-3rdparty
imx6q-dms-ba16	Advantech DMS BA16	i.MX6Q	meta-freescale-3rdparty
imx6qdl-variscite-som	Variscite i.MX6Q/DL VAR-SOM-MX6	i.MX6Q/DL	meta-freescale-3rdparty
imx6qdl-sabreauto	NXP i.MX6QP/Q/DL SABRE Automotive	i.MX6QP/Q/DL	meta-freescale
imx6qdl-sabresd	NXP i.MX6QP/Q/DL SABRE Smart Device	i.MX6QP/Q/DL	meta-freescale
imx6qsabrelite	Boundary Devices i.MX6Q SABRE Lite	i.MX6Q	meta-freescale-3rdparty
imx6sl-warp	WaRP	i.MX6SL	meta-freescale-3rdparty
imx6slevk	NXP i.MX6SL Evaluation Kit	i.MX6SL	meta-freescale
imx6sllevk	Freescale i.MX6SLL Evaluation Kit	i.MX6SLL	meta-freescale
imx6sxsabreauto	NXP i.MX6SoloX Sabre Automotive	i.MX6SX	meta-freescale
imx6sxsabresd	NXP i.MX6SoloX SabreSD	i.MX6SX	meta-freescale
imx6ul-pico-hobbit	Hobbitboard (PICO-IMX6UL)	i.MX6UL	meta-freescale-3rdparty
imx6ul-pico-pi	PICO-PI (PICO-IMX6UL)	i.MX6UL	meta-freescale-3rdparty
imx6ulevk	NXP i.MX6UL Evaluation Kit	i.MX6UL	meta-freescale
imx6ullevk	Freescale i.MX6ULL Evaluation Kit	i.MX6ULL	meta-freescale
imx7d-pico	IMX7D-PICO	i.MX7D	meta-freescale-3rdparty
imx7dsabresd	NXP i.MX7D SABRE Smart Device	i.MX7D	meta-freescale
imx7s-warp	WaRP7	i.MX7S	meta-freescale-3rdparty
imx7ulpevk	NXP i.MX7ULP Evaluation Kit	i.MX7ULP	meta-freescale
ls1012afrdm	NXP LS1012AFRDM board	LSCH2	meta-freescale
ls1012afrdm-32b	NXP LS1012AFRDM board	LSCH2	meta-freescale
ls1012ardb	NXP LS1012ARDB board	LSCH2	meta-freescale
ls1012ardb-32b	NXP LS1012ARDB board	LSCH2	meta-freescale
ls1021atwr	NXP LS1021ATWR board	ls102xa	meta-freescale
ls1043ardb	NXP LS1043ARDB board	LSCH2	meta-freescale
ls1043ardb-32b	NXP LS1043ARDB-32B	LSCH2	meta-freescale
ls1046ardb	NXP LS1046ARDB	LSCH2	meta-freescale
ls1046ardb-32b	NXP LS1046ARDB	LSCH2	meta-freescale

Continued on next page

Table 1 – continued from previous page

Machine	Name	SoC	Layer
ls1088ardb	NXP LS1088ARDB	LSCH3	meta-freescale
ls2080ardb	NXP LS2080ARDB board	LSCH3	meta-freescale
ls2088ardb	NXP LS2088ARDB	LSCH3	meta-freescale
m28evk	DENX M28 SoM Evaluation Kit	i.MX28	meta-freescale-3rdparty
m53evk	DENX M53 SoM Evaluation Kit	i.MX53	meta-freescale-3rdparty
nitrogen6sx	Boundary Devices Nitrogen6SX	i.MX6SX	meta-freescale-3rdparty
nitrogen6x	Boundary Devices Nitrogen6X	i.MX6 Q/DL	meta-freescale-3rdparty
nitrogen6x-lite	Boundary Devices Nitrogen6X Lite	i.MX6S	meta-freescale-3rdparty
nitrogen7	Boundary Devices Nitrogen7	i.MX7D	meta-freescale-3rdparty
pcm052	Phytec phyCORE Vybrid Development Kit	vf60	meta-freescale-3rdparty
tx6q-10x0	Ka-Ro electronics i.MX6Q TX6Q Computer-On-Module	i.MX6Q	meta-freescale-3rdparty
tx6q-11x0	Ka-Ro electronics i.MX6Q TX6Q Computer-On-Module	i.MX6Q	meta-freescale-3rdparty
tx6s-8034	Ka-Ro electronics i.MX6S TX6S Computer-On-Module	i.MX6S	meta-freescale-3rdparty
tx6s-8035	Ka-Ro electronics i.MX6S TX6S Computer-On-Module	i.MX6S	meta-freescale-3rdparty
tx6u-8033	Ka-Ro electronics i.MX6DL TX6DL Computer-On-Module	i.MX6DL	meta-freescale-3rdparty
tx6u-80x0	Ka-Ro electronics i.MX6DL TX6DL Computer-On-Module	i.MX6DL	meta-freescale-3rdparty
tx6u-81x0	Ka-Ro electronics i.MX6DL TX6DL Computer-On-Module	i.MX6DL	meta-freescale-3rdparty
ventana	i.MX6Q/DL Ventana Platform	i.MX6Q/DL	meta-freescale-3rdparty
wandboard	Wandboard i.MX6 Quad-Plus/Quad/Dual/Solo	i.MX6QP/Q/DL	meta-freescale-3rdparty

4.5.1 Machine Maintainers

Since FSL Community BSP Release 1.6 (Daisy), the maintainer field in machine configuration files of **meta-freescale** and **meta-freescale-3rdparty** is mandatory for any new board to be added.

So now on, every new board must have someone assigned as maintainer. This ensures, in long term,

all boards with a maintainer assigned. Current orphan boards are not going to be removed unless it causes maintenance problem and the fix is not straightforward.

The maintainer duties:

- The one with casting vote when a deadlock is faced.
- Responsible to keep that machine working (that means, booting and with some stability)
Keep kernel, u-boot updated/tested/working.
- Keep release notes updated
- Keep test cycle updated
- Keep the most usual images building and booting

When a build error is detected, the maintainer will “fix” it. For those maintainers with kernel control (meta-freescale-3rdparty), it is expected that they properly fix the kernel issue (when it’s a kernel issue). However, anything out of community control should be worked around anyway.

Machines with maintainers

Table 2: Machines with maintainers

Machine	Name
apalis-imx6	Toradex Apalis iMX6Q/D
cfa10036	Crystallfontz CFA-10036
cfa10037	Crystallfontz CFA-10037
cfa10049	Crystallfontz CFA-10049
cfa10055	Crystallfontz CFA-10055
cfa10056	Crystallfontz CFA-10056
cfa10057	Crystallfontz CFA-10057
cfa10058	Crystallfontz CFA-10058
cgtqmx6	Congatec QMX6 Evaluation board
cm-fx6	CompuLab CM-FX6
colibri-imx6	Toradex Colibri iMX6DL/S
colibri-imx7	Toradex Colibri iMX7D/S
colibri-vf	Toradex Colibri VF50/VF61
cubox-i	SolidRun CuBox-i and HummingBoard
imx23evk	NXP i.MX23 Evaluation Kit
imx25pdk	NXP i.MX25 Evaluation Kit
imx28evk	NXP i.MX28 Evaluation Kit
imx51evk	NXP i.MX51 Evaluation Kit
imx53ard	NXP i.MX53 SABRE Automotive Board
imx53qsb	NXP i.MX53 Quick Start Board
imx6dl-riotboard	RIoTboard
imx6q-dms-ba16	Advantech DMS BA16
imx6qdl-variscite-som	Variscite i.MX6Q/DL VAR-SOM-MX6
imx6qdl-sabreauto	NXP i.MX6QP/Q/DL SABRE Automotive

Continued on next page

Table 2 – continued from previous page

Machine	Name
imx6qdlSabresd	NXP i.MX6QP/Q/DL SABRE Smart Device
imx6qsabreLite	Boundary Devices i.MX6Q SABRE Lite
imx6sl-warp	WaRP
imx6slevk	NXP i.MX6SL Evaluation Kit
imx6sllevk	Freescall i.MX6SLL Evaluation Kit
imx6sxsabreauto	NXP i.MX6SoloX Sabre Automotive
imx6sxsabresd	NXP i.MX6SoloX SabreSD
imx6ul-pico-hobbit	Hobbitboard (PICO-IMX6UL)
imx6ulevk	NXP i.MX6UL Evaluation Kit
imx6ullevk	Freescall i.MX6ULL Evaluation Kit
imx7d-pico	IMX7D-PICO
imx7dsabresd	NXP i.MX7D SABRE Smart Device
imx7s-warp	WaRP7
imx7ulpevk	NXP i.MX7ULP Evaluation Kit
ls1012afRDM-32b	NXP LS1012AFRDM board
ls1012arDb	NXP LS1012ARDB board
ls1021atwr	NXP LS1021ATWR board
ls1043arDb	NXP LS1043ARDB board
ls1043arDb-32b	NXP LS1043ARDB-32B
ls1046arDb	NXP LS1046ARDB
ls1088arDb	NXP LS1088ARDB
ls2080arDb	NXP LS2080ARDB board
ls2088arDb	NXP LS2088ARDB
nitrogen6sx	Boundary Devices Nitrogen6SX
nitrogen6x	Boundary Devices Nitrogen6X
nitrogen6x-lite	Boundary Devices Nitrogen6X Lite
nitrogen7	Boundary Devices Nitrogen7
pcm052	Phytec phyCORE Vybrid Development Kit
tx6q-11x0	Ka-Ro electronics i.MX6Q TX6Q Computer-On-Module
tx6s-8035	Ka-Ro electronics i.MX6S TX6S Computer-On-Module
tx6u-8033	Ka-Ro electronics i.MX6DL TX6DL Computer-On-Module
ventana	i.MX6Q/DL Ventana Platform
wandboard	Wandboard i.MX6 Wandboard Quad-Plus/Quad/Dual/Solo

Machines without a maintainer

Table 3: Machines without a maintainer

Machine	Name
imx233-olinuxino-maxi	OLIMEX iMX233-OLinuXino-Maxi
imx233-olinuxino-micro	OLIMEX iMX233-OLinuXino-Micro
imx233-olinuxino-mini	OLIMEX iMX233-OLinuXino-Mini
imx233-olinuxino-nano	OLIMEX iMX233-OLinuXino-Nano
imx6ul-pico-pi	PICO-PI (PICO-IMX6UL)
m28evk	DENX M28 SoM Evaluation Kit
m53evk	DENX M53 SoM Evaluation Kit

SOFTWARE ARCHITECTURE

5.1 SoC Hierarchy

The following tree shows the SoC hierarchy:

5.2 Linux Kernel

FSL Community BSP supports the following sources for Linux Kernel:

- **linux-advantech:** linux-advantech version 4.1-r0.
- **linux-boundary:** Linux kernel for Boundary Devices boards.
- **linux-cfa:** Linux kernel for Crystalfontz boards.
- **linux-compulab:** Linux kernel for CompuLab cm-fx6 boards.
- **linux-congatec:** linux-congatec version 4.1.15-r0.
- **linux-denx:** DENX mainline based Linux kernel.
- **linux-fslc:** Linux kernel based on mainline kernel used by FSL Community BSP in order to provide support for some backported features and fixes, or because it was applied in linux-next and takes some time to become part of a stable version, or because it is not applicable for upstreaming.
- **linux-fslc-imx:** Linux kernel based on NXP 4.1.15-1.2.0 GA release, used by FSL Community BSP in order to provide support for i.MX based platforms and include official Linux kernel stable updates, backported features and fixes coming from the vendors, kernel community or FSL Community itself.
- **linux-gateworks-imx:** linux-gateworks-imx version 3.14-r0.
- **linux-imx:** Linux Kernel provided and supported by NXP with focus on i.MX Family Reference Boards. It includes support for many IPs such as GPU, VPU and IPU.
- **linux-karo:** Linux Kernel for Ka-Ro electronics TX Computer-On-Modules.
- **linux-qoriq:** Linux Kernel for Freescale QorIQ platforms.

- **linux-timesys**: Linux Kernel with added drivers and board support for Vybrid-based platforms.
- **linux-toradex**: Linux kernel for Toradex Freescale i.MX based modules.
- **linux-variscite**: linux-variscite version 4.1.15-r0.
- **linux-wandboard**: Linux kernel for Wandboard.
- **linux-warpp7**: Linux kernel based on linux-fsl-imx branch 4.1-1.0.x-imx from FSL Community BSP with additional patches to cover devices specific on WaRP7 board.

As stated in *Kernel Release Notes*, FSL Community BSP is not responsible for the Linux Kernel content in any kernel provider. If you are looking for the feature list, supported devices, official way to get a support channel or how to report bug, please, see above where to get help, for each kernel provider.

- **linux-imx**: provider, Freescale has a release notes document for each version released. This document has a list of known issues, new features, list of kernel arguments, and the linux-imx kernel scope for each Freescale Reference Board. This document is present into the Document Bundle provided by Freescale.

5.2.1 Default Linux Providers

The following table shows the default version of Linux Kernel provided by FSL Community BSP for each supported machine.

Table 1: Default Linux kernel version for each supported machine

Board	Kernel Provider	Kernel Version
apalis-imx6	linux-toradex	4.1-2.0.x+git
cfa10036	linux-cfa	4.1.13
cfa10037	linux-cfa	4.1.13
cfa10049	linux-cfa	4.1.13
cfa10055	linux-cfa	4.1.13
cfa10056	linux-cfa	4.1.13
cfa10057	linux-cfa	4.1.13
cfa10058	linux-cfa	4.1.13
cgtqmx6	linux-congatec	4.1.15
cm-fx6	linux-compulab	3.14.28-cm-fx6
colibri-imx6	linux-toradex	4.1-2.0.x+git
colibri-imx7	linux-toradex	4.1-2.0.x+git
colibri-vf	linux-toradex	4.4+git
cubox-i	linux-fslc	4.14+git
imx233-olinuxino-maxi	linux-fslc	4.14+git
imx233-olinuxino-micro	linux-fslc	4.14+git
imx233-olinuxino-mini	linux-fslc	4.14+git
imx233-olinuxino-nano	linux-fslc	4.14+git

Continued on next page

Table 1 – continued from previous page

Board	Kernel Provider	Kernel Version
imx23evk	linux-fslc	4.14+git
imx25pdk	linux-fslc	4.14+git
imx28evk	linux-fslc	4.14+git
imx51evk	linux-fslc	4.14+git
imx53ard	linux-fslc	4.14+git
imx53qsb	linux-fslc	4.14+git
imx6dl-riotboard	linux-fslc	4.14+git
imx6q-dms-ba16	linux-advantech	4.1-4.1-1.0.x-imx-dms-ba16
imx6qdl-variscite-som	linux-variscite	4.1.15-1.1.0
imx6qdsabreauto	linux-fslc-imx	4.1-2.0.x+git
imx6qdsabresd	linux-fslc-imx	4.1-2.0.x+git
imx6qsabrelite	linux-boundary	4.1.15-2.0.0-ga+yocto
imx6sl-warp	linux-fslc-imx	4.1-2.0.x+git
imx6slevk	linux-fslc-imx	4.1-2.0.x+git
imx6sllevk	linux-imx	4.9.11-1.0.0
imx6sxsabreauto	linux-fslc-imx	4.1-2.0.x+git
imx6sxsabresd	linux-fslc-imx	4.1-2.0.x+git
imx6ul-pico-hobbit	linux-fslc	4.14+git
imx6ul-pico-pi	linux-fslc	4.14+git
imx6ulevk	linux-fslc-imx	4.1-2.0.x+git
imx6ullevk	linux-imx	4.9.11-1.0.0
imx7d-pico	linux-fslc	4.14+git
imx7dsabresd	linux-fslc-imx	4.1-2.0.x+git
imx7s-warp	linux-warp7	4.1-4.1-1.0.x-imx-warp7
imx7ulpevk	linux-imx	4.9.11-1.0.0
ls1012afrdm	linux-qoriq	4.9
ls1012afrdm-32b	linux-qoriq	4.9
ls1012ardb	linux-qoriq	4.9
ls1012ardb-32b	linux-qoriq	4.9
ls1021atwr	linux-qoriq	4.9
ls1043ardb	linux-qoriq	4.9
ls1043ardb-32b	linux-qoriq	4.9
ls1046ardb	linux-qoriq	4.9
ls1046ardb-32b	linux-qoriq	4.9
ls1088ardb	linux-qoriq	4.9
ls2080ardb	linux-qoriq	4.9
ls2088ardb	linux-qoriq	4.9
m28evk	linux-fslc	4.14+git
m53evk	linux-denx	3.9-master
nitrogen6sx	linux-boundary	4.1.15-2.0.0-ga+yocto
nitrogen6x	linux-boundary	4.1.15-2.0.0-ga+yocto
nitrogen6x-lite	linux-boundary	4.1.15-2.0.0-ga+yocto
nitrogen7	linux-boundary	4.1.15-2.0.0-ga+yocto

Continued on next page

Table 1 – continued from previous page

Board	Kernel Provider	Kernel Version
pcm052	linux-timesys	3.13
tx6q-10x0	linux-karo	3.16-2015-09-18
tx6q-11x0	linux-karo	3.16-2015-09-18
tx6s-8034	linux-karo	3.16-2015-09-18
tx6s-8035	linux-karo	3.16-2015-09-18
tx6u-8033	linux-karo	3.16-2015-09-18
tx6u-80x0	linux-karo	3.16-2015-09-18
tx6u-81x0	linux-karo	3.16-2015-09-18
ventana	linux-gateworks-imx	3.14-1.0.x-ga+yocto
wandboard	linux-wandboard	4.1-2.0.x

5.3 Bootloaders

FSL Community BSP supports barebox and u-boot as bootloaders.

- **barebox:** Barebox - a bootloader that inherits the best of U-Boot and the Linux kernel
- **u-boot-congatec:** u-boot which includes support for Congatec Boards.
- **u-boot-fslc:** U-Boot based on mainline U-Boot used by FSL Community BSP in order to provide support for some backported features and fixes, or because it was submitted for revision and it takes some time to become part of a stable version, or because it is not applicable for upstreaming.
- **u-boot-imx:** i.MX U-Boot supporting i.MX reference boards.
- **u-boot-karo:** u-boot for Ka-Ro electronics TX Computer-On-Modules.
- **u-boot-qoriq:** U-Boot provided by Freescale with focus on QorIQ boards
- **u-boot-toradex:** U-Boot bootloader with support for Toradex Computer on Modules.
- **u-boot-variscite:** U-Boot for Variscite i.MX6Q/DL VAR-SOM-MX6.

The following table shows the default bootloaders (and their versions) for the supported boards.

Table 2: Default bootloader version for each supported machine

Board	Bootloader	Bootloader version
apalis-imx6	u-boot-toradex	2016.11+git
cfa10036	barebox	2015.10.0
cfa10037	barebox	2015.10.0
cfa10049	barebox	2015.10.0
cfa10055	barebox	2015.10.0
cfa10056	barebox	2015.10.0
cfa10057	barebox	2015.10.0

Continued on next page

Table 2 – continued from previous page

Board	Bootloader	Bootloader version
cfa10058	barebox	2015.10.0
cgtqmx6	u-boot-congatec	2016.01
cm-fx6	u-boot-fslc	v2017.11+git
colibri-imx6	u-boot-toradex	2016.11+git
colibri-imx7	u-boot-toradex	2016.11+git
colibri-vf	u-boot-toradex	2016.11+git
cubox-i	u-boot-fslc	v2017.11+git
imx233-olinuxino-maxi	u-boot-fslc	v2017.11+git
imx233-olinuxino-micro	u-boot-fslc	v2017.11+git
imx233-olinuxino-mini	u-boot-fslc	v2017.11+git
imx233-olinuxino-nano	u-boot-fslc	v2017.11+git
imx23evk	u-boot-fslc	v2017.11+git
imx25pdk	u-boot-fslc	v2017.11+git
imx28evk	u-boot-fslc	v2017.11+git
imx51evk	u-boot-fslc	v2017.11+git
imx53ard	u-boot-fslc	v2017.11+git
imx53qsb	u-boot-fslc	v2017.11+git
imx6dl-riotboard	u-boot-fslc	v2017.11+git
imx6q-dms-ba16	u-boot-fslc	v2017.11+git
imx6qdl-variscite-som	u-boot-variscite	2015.04
imx6qdsabreauto	u-boot-fslc	v2017.11+git
imx6qdsabresd	u-boot-fslc	v2017.11+git
imx6qsabrelite	u-boot-fslc	v2017.11+git
imx6sl-warp	u-boot-fslc	v2017.11+git
imx6slevk	u-boot-fslc	v2017.11+git
imx6sllevk	u-boot-imx	2017.03-nxp/imx_v2017.03_4.9.11_1.0.0_ga
imx6sxsabreauto	u-boot-imx	2017.03-nxp/imx_v2017.03_4.9.11_1.0.0_ga
imx6sxsabresd	u-boot-fslc	v2017.11+git
imx6ul-pico-hobbit	u-boot-fslc	v2017.11+git
imx6ul-pico-pi	u-boot-fslc	v2017.11+git
imx6ulevk	u-boot-fslc	v2017.11+git
imx6ullevk	u-boot-imx	2017.03-nxp/imx_v2017.03_4.9.11_1.0.0_ga
imx7d-pico	u-boot-fslc	v2017.11+git
imx7dsabresd	u-boot-fslc	v2017.11+git
imx7s-warp	u-boot-fslc	v2017.11+git
imx7ulpevk	u-boot-fslc	v2017.11+git
ls1012afrdm	u-boot-qorik	2017.09+fslgit+fsl
ls1012afrdm-32b	u-boot-qorik	2017.09+fslgit+fsl
ls1012ardb	u-boot-qorik	2017.09+fslgit+fsl
ls1012ardb-32b	u-boot-qorik	2017.09+fslgit+fsl
ls1021atwr	u-boot-qorik	2017.09+fslgit+fsl
ls1043ardb	u-boot-qorik	2017.09+fslgit+fsl
ls1043ardb-32b	u-boot-qorik	2017.09+fslgit+fsl

Continued on next page

Table 2 – continued from previous page

Board	Bootloader	Bootloader version
ls1046ardb	u-boot-qoriq	2017.09+fslgit+fsl
ls1046ardb-32b	u-boot-qoriq	2017.09+fslgit+fsl
ls1088ardb	u-boot-qoriq	2017.09+fslgit+fsl
ls2080ardb	u-boot-qoriq	2017.09+fslgit+fsl
ls2088ardb	u-boot-qoriq	2017.09+fslgit+fsl
m28evk	u-boot-fslc	v2017.11+git
m53evk	u-boot-fslc	v2017.11+git
nitrogen6sx	u-boot-fslc	v2017.11+git
nitrogen6x	u-boot-fslc	v2017.11+git
nitrogen6x-lite	u-boot-fslc	v2017.11+git
nitrogen7	u-boot-fslc	v2017.11+git
pcm052	u-boot-fslc	v2017.11+git
tx6q-10x0	u-boot-karo	v2015.10-rc2+git
tx6q-11x0	u-boot-karo	v2015.10-rc2+git
tx6s-8034	u-boot-karo	v2015.10-rc2+git
tx6s-8035	u-boot-karo	v2015.10-rc2+git
tx6u-8033	u-boot-karo	v2015.10-rc2+git
tx6u-80x0	u-boot-karo	v2015.10-rc2+git
tx6u-81x0	u-boot-karo	v2015.10-rc2+git
ventana	u-boot-gateworks-imx	v2015.04+git
wandboard	u-boot-fslc	v2017.11+git

5.4 User Space Packages

There is a huge number of user space packages provided by the Yocto Project. The following table shows some version for few highlighted packages.

Table 3: Main user space package versions

Package	Board/SoC Family	Version
gststreamer1.0	All	1.12.2
udev	All	3.2.2

5.4.1 Freescale User Space Packages

This section shows the version package for each board. Those packages provide hardware acceleration for GPU or VPU, hardware optimization or some hardware test tools.

- **Hardware acceleration** is achieved using a different core for processing some specific task. In this case, GPU or VPU.
- **Hardware optimization** is achieved with some changes in source code in order to get a better performance for a specific task on a specific hardware. For example, audio decode made by software, but with optimizations for ARM.

- **Hardware-specific** is applicable when the package was designed to be executed on a specific hardware, and it does not make sense on other hardware. For example, imx-test is a test package for imx boards. It can be cross-compiled for any other core, although it will only behave as expected if executed on imx boards.

The package version and variety varies on *SoC Hierarchy*. For example, machines with i.MX28 SoC does not have VPU, the recipe imx-vpu is not needed. There are differences, as well, in GPU support recipes.

Version by SoC Hierarchy

The following table shows the version of each package depending on the *SoC Hierarchy*.

Table 4: User space package version by SoC hierarchy

Package name	ls102xa	mx28	mx5	mx6q / mx6dl	mx6sl	vf60
apptrk	git	–	–	–	–	–
cst	git	git	git	git	git	git
devregs	1.0+AU-TOINC+34ed402b92	1.0+AU-TOINC+34ed402b92	1.0+AU-TOINC+34ed402b92	1.0+AU-TOINC+34ed402b92	1.0+AU-TOINC+34ed402b92	1.0+AU-TOINC+34ed402b92
directfb	1.7.7	1.7.7	1.7.7	1.7.7	1.7.7	1.7.7
directfb-examples	1.7.0	1.7.0	1.7.0	1.7.0	1.7.0	1.7.0
elftosb	10.12.01	10.12.01	10.12.01	10.12.01	10.12.01	10.12.01
firmware-imx	5.4	5.4	5.4	5.4	5.4	5.4
fsl-alsa-plugins	–	–	–	1.0.26	1.0.26	–
gpu-viv-bin-mx6q	–	–	–	–	–	–
gpu-viv-g2d	–	–	–	–	–	–
gst1.0-fsl-plugin	–	–	–	–	–	–
gststreamer1.0-plugins-imx	–	–	–	0.13.0	0.13.0	–
imx-kobs	–	5.5+git	5.5+git	5.5+git	5.5+git	5.5+git
imx-lib	–	–	–	5.8+AU-TOINC+f5f14fc245	5.8+AU-TOINC+f5f14fc245	–
imx-test	–	00.00.00	00.00.00	6.0+AU-TOINC+fb250a795c	6.0+AU-TOINC+fb250a795c	00.00.00
imx-uuc	0.5.1+git	0.5.1+git	0.5.1+git	0.5.1+git	0.5.1+git	0.5.1+git
imx-vpu	–	–	–	5.4.37	5.4.37	–
libfslcodec	–	–	–	4.2.1	4.2.1	–
libfslparser	–	–	–	4.2.1	4.2.1	–
libfs-lvpwrap	–	–	–	1.0.68	–	–
libmcc	–	–	–	–	–	1.05.1
mqxboot	–	–	–	–	–	1.0.1
mxsldr	0.0.0+git	0.0.0+git	0.0.0+git	0.0.0+git	0.0.0+git	0.0.0+git
qe-ucode	git	–	–	–	–	–
qemu-fsl	–	–	–	–	–	–
rcw	git	–	–	–	–	–
xf86-video-imxfb	–	–	–	–	–	–
xf86-video-imxfb-vivante	–	–	–	–	–	–

Hardware relation by SoC Hierarchy

The following table shows how packages interact with hardware depending on the *SoC Hierarchy*

Table 5: Hardware dependent packages

Package Name	mx28	mx5	mx6	vf60
imx-test	HW-specific	HW-specific	HW-specific	–
gst-fsl-plugin	HW-specific	HW-specific	HW-specific	–
libfslcodec	HW optimization	HW acceleration	HW acceleration	–
libfslparser	HW optimization	HW optimization	HW optimization	–
imx-vpu	–	HW acceleration	HW acceleration	–
imx-lib	–	HW acceleration	HW acceleration	–
firmware-imx	–	HW-specific	HW-specific	–
mxsldr	HW-specific	–	–	–
gpu-viv-g2d	–	–	HW acceleration	–
xf86-video-imxfb-vivante	–	–	HW acceleration	–
gpu-viv-bin-mx6q	–	–	HW acceleration	–
directfb	–	–	HW acceleration	–
directfb-examples	–	–	HW acceleration	–
xf86-video-imxfb	–	HW acceleration	–	–
amd-gpu-bin-mx51	–	HW acceleration	–	–
libz160	–	HW acceleration	–	–
amd-gpu-x11-bin-mx51	–	HW acceleration	–	–
libfslvpuwrap	–	–	HW acceleration	–
fsl-alsa-plugins	–	–	HW-specific	–
gststreamer1.0-plugins-imx	–	–	HW acceleration	–
imx-uuc	HW-specific	HW-specific	HW-specific	–
libmcc	–	–	–	–
mqxboot	–	–	–	HW-specific

5.5 PackageGroups and Images

The FSL Community BSP provides a list of PACKAGEGROUPS and images intended to ease the initial development of custom applications.

The main goal is not to provide a production solution, on the contrary, it should be seen as an example of package set for a specific IP development, and an example of initial generic development and test images.

5.5.1 PACKAGEGROUPS

The following list shows the current PACKAGEGROUPs available in Rocko when using FSL Community BSP.

You can understand what a PACKAGEGROUPs is and learn how to use it in [Yocto Project Development Manual](#)

- **packagegroup-fsl-gstreamer1.0:** Package group used by FSL Community to provide audio, video, networking and debug GStreamer plugins with the required hardware acceleration (if supported by the SoC).
- **packagegroup-fsl-gstreamer1.0-full:** Package group used by FSL Community to provide all GStreamer plugins from the base, good, and bad packages, as well as the ugly and libav ones if commercial packages are whitelisted, and plugins for the required hardware acceleration (if supported by the SoC).
- **packagegroup-fsl-mfgtool:** Freescale Manufacturing Tool requirements.
- **packagegroup-fsl-tools-benchmark:** Package group used by FSL Community to provide a set of benchmark applications.
- **packagegroup-fsl-tools-gpu:** Package group used by FSL Community to add the packages which provide GPU support.
- **packagegroup-fsl-tools-gpu-external:** Package group used by FSL Community to provide graphic packages used to test the several hardware accelerated graphics APIs including packages not provided by Freescale.
- **packagegroup-fsl-tools-testapps:** Package group used by FSL Community to provide a set of packages and utilities for hardware test.
- **packagegroup-imx-tools-audio:** Set of audio tools for inclusion on images.

5.5.2 Images

The following images are provided by FSL Community BSP only. See the list of Yocto Project's reference images in [Yocto Project Reference Manual](#)

- **fsl-image-machine-test:** A console-only image that includes gstreamer packages, Freescale's multimedia packages (VPU and GPU) when available, and test and benchmark applications.
- **fsl-image-mfgtool-initramfs:** Small image to be used with Manufacturing Tool (mfg-tool) in a production environment.
- **fsl-image-multimedia:** A console-only image that includes gstreamer packages and Freescale's multimedia packages (VPU and GPU) when available for the specific machine.
- **fsl-image-multimedia-full:** A console-only image that includes gstreamer packages and Freescale's multimedia packages (VPU and GPU) when available for the specific machine.

5.5.3 Distro

The following distros are supported by FSL Community BSP.

- **fslc-framebuffer**: Distro for Framebuffer graphical backend. This distro doesn't include x11 and wayland features.
- **fslc-wayland**: Distro for Wayland without X11. This distro include wayland feature but doesn't has x11 support.
- **fslc-x11**: Distro for X11 without wayland. This distro include x11 feature and doesn' has wayland support.
- **fslc-xwayland**: Distro for Wayland with X11. This distro include both wayland and x11 features.

NOTE: Poky's distros are still available to use.

TEST RESULTS

Freescall has a complete test cycle for the BSP released. It includes tests for Linux Kernel for the GPU package and for the VPU package (and all other package needed by the BSP, such as imx-lib).

The results and known issues, from Linux Kernel, GPU and VPU packages can be found in the Freescale Release Notes (Download tab of freescale.com/imx).

For boards from meta-freescale-3rdparty, the test cycle is performed by each mantainer.

ACKNOWLEDGEMENTS

The FSL BSP Community is a community effort of keeping and maintaining a Freescale boards/chips layer for the Yocto Project.

7.1 Rocko Source Code

The statistics can be seen at the FSL Community BSP website. It has not been included here as it changes every time bug fixes are included during the maintenance cycle of the release and it would be outdated most of time.

KNOWN ISSUES

The list of known issues for the FSL Community BSP can be seen at the following URL:

<https://bugzilla.yoctoproject.org/buglist.cgi?quicksearch=meta-freescale>

It has not been included here as it changes every time bug fixes are included during the maintenance cycle of the release and it would be outdated most of time.