


Soldering the MYLAPS detection loop wires

Installation step 1

Apply two shrink sleeves before soldering the wire ends together. Do not shrink them yet.



Installation step 2

After soldering the wire ends together slide the small shrinksleeve over the connection and shrink it. To ensure a proper seal, slide the large shrinksleeve over the connection and fill it up with silicone before shrinking it.

