

SeaEra™

FLOOR TEMPLATE

MODELS:

162HR0** AND 162MR0**

Printing and
Assembly
Instructions.


⚠ IMPORTANT:

INSTRUCTIONS FOR PRINTING AND ASSEMBLING TEMPLATE.

1. Template is PDF format, for 8 1/2 x 11" paper.
2. Page Scaling: MUST PRINT FULL SCALE (1:1)
3. With scissors, cut on 'Dashed Lines'.  --- --- ---
4. Align sheets accordingly using Dashed Lines and corresponding Alignment Arrows and tape together.
5. Check that printed template is the correct scale (size) by measuring at the CHECK POINT on template (lower left). You should measure 7" (178mm).

⚠ IMPORTANT:

1. DO NOT DRILL OR CUT HOLES FROM THIS TEMPLATE. FOR REFERENCE ONLY,
2. REFER TO INSTALLATION MANUAL FOR INSTALLATION DETAILS.
3. CHINA BOWL DIMENSIONS CAN VARY +/-5%. CONSIDER THIS WHEN INSTALLING.
4. DIMENSIONS ARE: INCHES [MM]






WWW.RARITANENG.COM

SeaEra™

MODELS: 162



WWW.RARITANENG.COM



BOWL TYPE	A	B	C	D	E
MARINE	14 1/2 (368)	26 1/2 (673)	10 3/8 (264)	17 1/4 (438)	13 (330)
HOUSEHOLD	14 7/8 (378)	29 5/8 (752)	11 1/2 (292)	20 (508)	14 3/8 (365)

INTAKE	F
PRESSURIZED FRESH WATER	8 7/8 (225)
REMOTE PUMP	7 13/16 (199)

INCHES
(MM)

NOTE:

1. THE SEAT WILL OPEN WITHIN THE DEPTH OF THE BOWL (D), HOWEVER, IT MAY BE DESIRABLE TO INCREASE THIS ANGLE BY ALLOWING MORE ROOM AT THE BACK OF THE BOWL FOR THE SEAT TO OPEN.
2. DIMENSIONS ARE FOR REFERENCE AS VITREOUS CHINA DIMENSIONS MAY VARY +/- 5%.



WWW.RARITANENG.COM

SeaEra™


MODELS: 162HR0** AND 162MR0**

** : VOLTAGE 12 or 24

SHEET 1

THIS TEMPLATE SHOWS THE
LOWER BASE ASSEMBLY IN
THE STANDARD POSITION
AND ROTATED 90 DEGREES.

2



SHEET 2

H BOWL SIZE
(HOUSEHOLD SIZE BOWL)

M BOWL SIZE
(MARINE SIZE BOWL)

3


MOUNTING HOLES
(REFERENCE ONLY)


1



SHEET 3

2







SHEET 5

CHECK POINT

7
[1178]

MOUNTING HOLES (90)
(REFERENCE ONLY)

5



7





MOUNTING HOLES (90)
(REFERENCE ONLY)

6

SHEET 6

! IMPORTANT:

1. DO NOT DRILL OR CUT HOLES FROM THIS TEMPLATE. FOR REFERENCE ONLY,
2. REFER TO INSTALLATION MANUAL FOR INSTALLATION DETAILS.
3. CHINA BOWL DIMENSIONS CAN VARY +/-5%. CONSIDER THIS WHEN INSTALLING.
4. DIMENSIONS ARE: INCHES [MM]



Remote Intake
Pump
Scale: 1/2