

Эксплуатационные минимумы каждого из аэродромов, которые предполагается использовать в качестве аэродромов намеченной посадки или запасных аэродромов

ROSARIO / Islas Malvinas
Росарио

SAAR (B)

Argentina
Аргентина

LANDING MINIMUMS

RWY	A/c type	ILS	LOC (GS out)	VOR DME	VOR	CIRCLE-TO-LAND Not authorized East of RWY 02/20 Centerline		
						MDA (H)	CEIL	VIS
02	Falcon	-	-	-	-	800' (220m)	(1050') (320m)	3700
	B737	-	-	-	-	800' (220m)	(1050') (320m)	4600
20	Falcon	60x1200 279'	120x2000 470'	120x2000 470'	150x2400 570'	800' (220m)	(1050') (320m)	3700
	B737	60x1200 279'	120x2000 470'	120x2000 470'	150x2400 570'	800' (220m)	(1050') (320m)	4600

TAKE-OFF MINIMUMS*

RWY	A/c type	With Runway Centerline Lights (CL)	Without Runway Centerline Lights (CL) with Runway Lights (RL)		RCLM (without Runway Centerline Lights, without Runway Lights)	
			DAY	NIGHT (Runway End Identifier Lights are Needed)	DAY	NIGHT
02/20	Falcon	-	Vis 550m	Vis 550m	2500m	NA
	B737					

* - Minimums listed are applicable in case of Take-off Alternate Airport filled (2 hour 1 eng inoperative for Falcon and 1 hour 1 eng inoperative for Boeing), otherwise Take-off minimum is not below available Landing Minimum.

RWY Heading 016/196

RWY Dimensions 3000x45m

ARP Coordinates **S 32 54.2** **W 060 47.1**

AD Elevation 85'/ 26m

Дата утверждения	Дата введения в действие 19.07.2016	
------------------	--	--