




**N78HR**

Sheet: /Overview/  
File: overview.kicad\_sch

### Title: System Overview

Size: USLetter Date: 2025-09-09  
KiCad E.D.A. 9.0.4

Rev: 1.0.1  
Id: 1/10



IBBS Output has 10A fuse  
none needed here


#### N78HR


Sheet: /Lycoming/  
File: rotax.kicad\_sch


#### Title: Lycoming


Size: A Date: 2025-10-11  
KiCad E.D.A. 9.0.4

Rev: 1.1.7  
Id: 3/10









# N78HR

Sheet: /Communication/  
File: communication.kicad\_sch

## Title: Communication


Size: USLetter Date: 2025-10-01  
KiCad E.D.A. 9.0.4

Rev: 1.1  
Id: 7/10









**N78HR**

Sheet: /Autopilot/  
File: autopilot.kicad\_sch

**Title: Autopilot**

Size: USLetter Date: 2025-10-01  
KiCad E.D.A. 9.0.4

**Rev: 1.1.1**  
Id: 10/10