








BUZZER SECTION






RGB LED SECTION



WAKEUP AND RESET SWITCH



Micro SD Card Section



Title		
Size	Number	Revision
A4		
Date:	5/03/2021	Sheet of
File:	C:\Users\...\sdd_peripherals.SchDoc	Drawn By:



