





## Step 2: Creating the MX1508 Symbol in EAGLE


1. Right click the library created previously and click open to open the library window. Select the Symbol  icon and name your new symbol MX1508
2. Select  pin and place 16 pins. Left click to rotate.




3. Name the pins according to the datasheet. Use the Name tool as done when creating the package.



4. Click the line icon and add an outline



5. Add name and value placeholders as done for the package using the layers 95 Names and 96 Values



6. Done! Don't forget to save your work.