

Control

Maxigauge

Flowmeter

Status

Programming

Setup

4K Heater

Volts

30,00

Amps

2,00

Volts

0 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30

30

Amps

0

2

2

CC ☒

ON

**Off timer**

The output will be turned of after certain amount of time has passed after turn on to avoid accidental overheating of the system.

Off timer (hours)



15

Current status

Output is turned off.







