

### Step 3

**B003 Messages [Message texts]**

**Parameter** | Comment

Parameter

Block name:

**Message Text Setting**

Priority:

☐ Acknowledge Message

**Current character set selection**

☒ Character set 1: ISO8859\_1 ☒ Enabled

☐ Character set 2: ISO8859\_1 ☐ Enabled

**Contents**

**Block**

Search:

- ☒ B001 Voltage Amp [Analog Amplifier]
- ☒ B002 Temperature [Analog Amplifier]
- ☒ B004 Voltage Schm [Analog threshold trigger]
- ☒ B005 Temp Scmitt [Analog threshold trigger]

**Ticker setting**

☒ Character by character:

☐ Line by line:

☐ Line1 ☐ Line2 ☐ Line3 ☐ Line4 ☐ Line5 ☐ Line6

**Message Destination**

☐ LOGO! Display ☐ LOGO! TD ☒ Both ☒ Web server

**Parameter**

Gain

Offset

Ax, amplified

**Message Text**

☒ °C ☐ AI **ON/OFF** Symbol 00:00 Edit manually

Text	Unit	Value
V o l t a g e	V	0.00
T e m p	°C	-50.0