

## Prerequisites

### Required Information [*\*needed for final activation of hardware - see last page*]

- Name of asset\* (ex: Propane Truck #20)
- Detailed information about the asset\* (year, make, model, VIN, license plate, etc.)
- State, area, organization, or group the asset belongs to (ex: North Region, MN tankers, etc.)
- ESN of each device to be installed\* (ESN is found on the back of each unit with a barcode)
- Current odometer reading and engine hours
- Type of diagnostic connector, if possible (6 pin, 9 pin square flange, 9 pin round threaded, J1962, Type II, etc.)

### Required Equipment



**LMU**



**Driver ID "reader"**



**Accessory Harness**



**OBDII Cable**  
(if ordered)

**OR**



**Diagnostic Y Cable\*\***

\*\* Diagnostic Y Cables will vary depending on make, model, year of vehicle. The cable pictured may not be the exact cable shipped.

### Required Tools

- Drill and assorted drill bits
- Slotted, Philips, and/or Torx bits (you may need tamper resistant Torx bits)
- Panel removal tool or plastic pry bar (to remove dash panel(s) as needed)
- Small socket set
- Zip Ties (to hold cabling in place)



## Before You Begin

***TURN TO THE LAST PAGE - WRITE DOWN THE REQUIRED INFORMATION!!!***

- Decide where the hardware components will be located. If necessary remove any dash panels with removal tool.
- Device should be secured within reach of the diagnostic cable to be installed.
- Must be protected from moisture, excessive dust/dirt, heat (away from heater vents) and unobtrusive to driver operation or field of view.
- Routing of the cable between the factory diagnostic port and the telematics device does not cause excessive bending/kinking or areas where vibration may jeopardize the integrity of the hardware.
- Cabling must not impede function of any rotating or moving parts (ex. Steering mechanisms, wiper mechanisms, or brake pedal)
- Ensure that the mounting location has enough integrity to accommodate the additional weight and vibration of the device.

## Driver ID Cable

### STEP ONE

Attach bracket to dash with self-tapping screws. (If not preassembled, place o-ring behind light, feed through bracket, and secure with nut.)

Bracket should be located in clear view of the driver.

Driver ID Reader



### STEP TWO

Attach 6-pin plug from Driver ID Reader cable to the 6-pin plug on the accessory harness.



Accessory Harness

### STEP THREE

Attach the male 20 pin plug from the accessory harness into the port on the back of the telematics device.



LMU

Accessory Harness

## Connect to Asset Diagnostic Cable

Diagnostic Y cables will vary depending on make, model, year of vehicle. The cable pictured may not be the exact cable shipped. Be sure to verify that the diagnostic Y cable that you are installing is the correct cable for this asset.



### STEP ONE

Remove the vehicles's factory diagnostic cable from its factory mount.

### STEP TWO

Connect the factory cable to the female diagnostic connector of the diagnostic Y cable (rotate clockwise until it "clicks")

Replace original factory  
diagnostics port



Connect to factory  
diagnostics port



### STEP THREE

Replace the factory connector with the male diagnostic connector of the diagnostic Y cable.




*JBus style factory diagnostics port*

## Connect Diagnostic Cable to Telematics Device

### STEP FOUR

Run the 16 pin Molex connector to the location of the telematics device.



OBDDII Style Cable

OR



Jbus Style Cable

### STEP FIVE

Connect the 16 pin Molex connector to the back of the telematics device.



LMU

### STEP SIX

Securely mount the telematics device without metal obstruction between device and the sky if mounting inside the dash area. (Label side faces the sky.)

## Testing / Confirmation Steps

**STEP EIGHT** When the ignition is on, the Driver ID Reader's LED light ring will flash green until tapped with the keyfob hardware, making a driver connection to the asset, which will turn the light solid green and then the light will turn off. **It is NOT necessary to use a keyfob for installation.** Just be aware that the light will continue to flash when the key is in the ignition and also while the engine is running during installation.



Driver ID Reader  
Ignition On = Flash Green




Example  
Driver Keyfob



## Testing / Confirmation Steps *continued*

- **Start** the asset's engine and let it run.
- LED indicator lights will blink then turn solid. (Green/GPS & Orange/Comm)
- If the lights continue to blink, reconfirm all connections.



Call Pedigree Technologies support to confirm installation **before** replacing any of the dash panels you may have removed during cable installation.

### Install Confirmation: 701-499-0022

You will be prompted for the following information during the set up process

- Device ESN
- Name of Asset (ex. Service Truck 51)
- Year, make, and model
- VIN #
- License plate #
- Mileage  Hours