

② Front end of a sub frame

- Mislocation of the front end of a sub frame may result in cracks in a chassis frame in that area, or deterioration in ride comfort. The distance between the rear face of cab back and the front end of a sub frame should be no longer than 200mm.

**Position of the sub frame front end**

