


Antenna needs to be connected
through the on-chip SMA connector.

Place C20, C21, and C22 as close
as possible to pin 1, in that order.



Sheet: /base-transceiver/
File: base-transceiver.sch

Title: Base - Transceiver

Size: A4 Date: March 4, 2017

KiCad E.D.A. kicad 4.0.5

Rev: 0.1

Id: 2/2