

L ~ N

AC

HestiaPi Touch v3.0  
www.hestiacpi.com



open hardware

For instructions visit [hestiacpi.com/guides](http://hestiacpi.com/guides)

AC\*-  
5V



R2

-

+5VDC



Q2



Q1



R1



D2



D1

Hot  
Water

Heating

Wi-Fi

16 GND 12 GND SC 07 08 25 GND 24 23 GND 18 15 14 GND 5V 5V 3.3\*/5V

19 13 06 05 SD GND 11 09 10 3V3 22 27 17 GND 04 SCL SDA 3V3

Raspberry Pi Zero

H

W

AC~

Humidity! D

NC

-

SCL

SDA