



**Team ID:** PNT2022TMID04707

Step 1:



Step 2



### Step 3:

IBM Watson IoT Platform

Browse Action Device Types Interfaces

### Add Device

Identity Device Information Security Summary

Select a device type for the device that you are adding and give the device a unique ID.

Device Type: NodeMCU

Device ID: 12345

Cancel Next

Browse Devices

### Step 4:

### Step 5:

IBM Watson IoT Platform

Browse Action Device Types Interfaces

### Add Device

Identity Device Information Security Summary

Verify that the following information is correct then select Finish

Device Type: NodeMCU

Device ID: 12345

View Metadata

Security Token: 87654321

Back Finish

## Device Drilldown - 12345

### Device Credential

CoonectiOf1 In!ormatiOn

## Recent Events

Slate

## Device Information

## Metadata

## Diagnostics

Coonectioo log-;

## Device Actions

## Device Credentials

[illegible]

Organization ID	ck2tf0
DeviceType	lliotMCU
01111ceto	12145
Authenticat ion Method	Use-token-aut1
Authent icat ion Token	8765,4321

**A** Author!eiuntoko-n's ,!llo non-roceovorable.If you mispfect thi•!okr,n,you willnocd!0ro-rogi!or thetdcvice to gcnor:il0 a nctw:auth!nt,e:ltion token.

Findout howto add thesecredenhabto your GeV,ce "