


Create and Configure IBM services

IOT Watson Platform


SmartFarmer - IoT Enabled Smart Farming Application

Team ID: PNT2022TMID48188


Step1: Log in your registered id




Step 2: click catalog where you find the services and internet of thing you can select and make location as London




Step 3: click create and the launch tab get open, then click launch




Step 4: It redirect you to IBM WATSON platform where you need to click sign in




Step 5: you need to log in IBM ID




Step 6: where you find this tab which is used to add device , app, member ,usage , security can be worked



Step 7: check boards for risk and security overview card , it uses for graphical representation boards



Step 8: after clicking create a new device / add device you can choose an device type and device id and complete the following information to create a device



Step 9: created a device of NodeMCU

[← Back](#)

Device Drilldown - 12345

Device Credentials

[Connection Information](#)[Recent Events](#)[State](#)[Device Information](#)[Metadata](#)[Diagnostics](#)[Connection Logs](#)[Device Actions](#)

Device Credentials

You registered your device to the organization. Add these credentials to the device to connect it to the platform. After the device is connected, you can navigate to view connection and event details.

Organization ID	m5ttid
Device Type	NodeMCU
Device ID	12345
Authentication Method	use-token-auth
Authentication Token	12345678



Authentication tokens are non-recoverable. If you misplace this token, you will need to re-register the device to generate a new authentication token.

[Find out how to add these credentials to your device](#)