


# Create and Configure IBM servicesIoT Watson Platform SmartFarmer - IoT Enabled Smart Farming Application


Team ID: PNT2022TMID16870

Date:08/11/2022


Step1: Log in your registered id




Step 2: click catalog where you find the services and internet of thing you can select and make location as London




Step 3: click create and the launch tab get open, then click launch




Step 4: It redirect you to IBM WATSON platform where you need to click sign in



Step 5: you need to log in IBM ID




Step 6: where you find this tab which is used to add device , app, member ,usage , security canbe worked




Step 7: check boards for risk and security overview card , it uses for graphical representationboards





Step 8: after clicking create a new device / add device you can choose an device type and deviceid and complete the following information to create a device



## Step 9: created a device of NodeMCU

IBM Watson IoT Platform

310619205051@smartinternz.com  
ID: m5ttid

← Back

Device Drilldown - 12345

Device Credentials

Connection Information

Recent Events

State

Device Information

Metadata

Diagnostics

Connection Logs

Device Actions

Device Credentials

You registered your device to the organization. Add these credentials to the device to connect it to the platform. After the device is connected, you can navigate to view connection and event details.

Organization ID	m5ttid
Device Type	NodeMCU
Device ID	12345
Authentication Method	use-token-auth
Authentication Token	12345678

⚠

Authentication tokens are non-recoverable. If you misplace this token, you will need to re-register the device to generate a new authentication token.

Find out how to add these credentials to your device