


V.S.B. Engineering College
Department of Computer Science
And Engineering
IOT Assignment

Topic: Assignment On Home Automation Using Arduino

Name: ABISHEK S

CIRCUIT DIAGRAM:



CODE:

```
#include<Servo.h>
const int pingPin = 7;
int servoPin = 8;
Servo servo1;
void setup()
{
```

```
Serial.begin(9600);
servo1.attach(servoPin);
pinMode(2,INPUT);

pinMode(4,OUTPUT);

pinMode(11,OUTPUT);

pinMode(12,OUTPUT);

pinMode(13,OUTPUT);

pinMode(A0,INPUT);

digitalWrite(2,LOW);

digitalWrite(11,HIGH);
}

void loop()
{

    long duration, inches, cm;

    pinMode(pingPin, OUTPUT);

    digitalWrite(pingPin, LOW);

    delayMicroseconds(2);

    digitalWrite(pingPin, HIGH);

    delayMicroseconds(5);
```

```
digitalWrite(pingPin, LOW);

pinMode(pingPin, INPUT);

duration = pulseIn(pingPin, HIGH);

inches = microsecondsToInches(duration);

cm = microsecondsToCentimeters(duration);

Serial.print(inches);
Serial.print("in, ");
Serial.print(cm);
Serial.print("cm");
Serial.println();
delay(100);

servo1.write(0);
if(cm < 40)
{
    servo1.write(90);
    delay(2000);
}
else
{
    servo1.write(0);
}

int pir = digitalRead(2);

if(pir == HIGH)
{
    digitalWrite(4,HIGH);
```

```
    delay(1000);  
}  
else if(pir == LOW)  
{  
    digitalWrite(4,LOW);  
}
```

```
float value=analogRead(A0);  
float temperature=value*0.48;
```

```
Serial.println("temperature");  
Serial.println(temperature);
```

```
if(temperature > 20)  
{  
    digitalWrite(12,HIGH);  
    digitalWrite(13,LOW);  
}  
else  
{  
    digitalWrite(12,LOW);  
    digitalWrite(13,LOW);  
}  
}
```

```
long microsecondsToInches(long microseconds)  
{  
    return microseconds / 74 / 2;  
}
```

```
long microsecondsToCentimeters(long microseconds)  
{  
    return microseconds / 29 / 2;  
}
```

OUTPUT:

