

Software

Project Title: Real-Time River Water Quality Monitoring and Control System

Team ID: PNT2022TMID42971

Procedure

- Install the Python IDLE.


Click https://www.youtube.com/watch?v=4Rx_JRkwAjY for the reference video of python installation.

- Install the required python libraries:


Install Watson IoT Python SDK, Cloudant DB, pyzbar, OpenCV to integrate Cloud services, capture the data from the camera, and process the data stored in QR code using the python code.

Install the above libraries using the commands listed below one after the other in the command prompt. ◦ **pip install wiotp-sdk** ◦ **pip install ibmcloudant** ◦ **pip install opencv-python** ◦ **pip install pyzbar**


Step 1: Type python.org




Step 2: Scroll down to **DOWNLOAD** and click [python 3.11.0](https://python.org/python/3.11.0/)




Step 3: Then scroll down to **Files** and click [Windows installer\(64-bit\)](#) as shown below.



Step 4: Open the **Download** in file then to install Click [python 3.11.0](#) , Then click **Add python.exe to PATH** And then click **Install now**



Step 6: After clicking Install now the setup will progress.



Step 7: After then it will add the windows on recent.

