



```

#include<Servo.h>
const int pingPin = 7;
int servoPin = 8;

Servo servol;

void setup() {
  // initialize serial communication:
  Serial.begin(9600);
  servol.attach(servoPin);
  pinMode(2, INPUT);
  pinMode(4, OUTPUT);
  pinMode(11, OUTPUT);
  pinMode(12, OUTPUT);
  pinMode(13, OUTPUT);
  pinMode(A0, INPUT);
  digitalWrite(2, LOW);
  digitalWrite(11, HIGH);
}

void loop() {

  long duration, inches, cm;

  pinMode(pingPin, OUTPUT);
  digitalWrite(pingPin, LOW);
  delayMicroseconds(2);
  digitalWrite(pingPin, HIGH);
  delayMicroseconds(5);
  digitalWrite(pingPin, LOW);

  // The same pin is used to read the signal from the PING))) : a HIGH pulse
  // whose duration is the time (in microseconds) from the sending of the ping
  // to the reception of its echo off of an object.
  pinMode(pingPin, INPUT);
  duration = pulseIn(pingPin, HIGH);

  // convert the time into a distance
  inches = microsecondsToInches(duration);
  cm = microsecondsToCentimeters(duration);

  //Serial.print(inches);
  //Serial.print("in, ");
  //Serial.print(cm);
  //Serial.print("cm");
  //Serial.println();
  //delay(100);
}

```