


## 5 - S71 CALC StartEnd notch


### ■ Description

Calculate the Start/End notch size based on the start/end detection in Category 1 "S10 Camera with StartEnd detection".

### ■ Icon



### ■ Parameters



Parameter	Comment
Verbosity level	Selection of verbosity level. Larger verbosity levels offer more overlay information.

Reference	Reference position for the notch measurement: <ul style="list-style-type: none"> <li>• Middle = center of left and right blank begin/end</li> <li>• Short side = blank begin/end which is nearer to the blanks inside</li> <li>• Long side = blank begin/end which is farther to the blanks inside</li> </ul>
Threshold	Every image pixel whose intensity is equal or bigger than threshold is treated as blank. [Greylevel]

■ Measured values for plotter

706		Notch Size
-----	--	------------

■ Subgraphs interface

IN bridges

OUT bridges

<div>image</div> <div>Start end Info</div> <div>value</div>	<div>Img</div> <div>Start end Info</div> <div>Seam pos left</div> <div>Seam pos right</div>		
-------------------------------------------------------------	---------------------------------------------------------------------------------------------	--	--

■ Graph block diagram

