

UUT Report

Station ID: IT-W-7303101  
Serial Number: NONE  
Date: venerdì 20 gennaio 2023  
Time: 12:11:42  
Operator: ITLAVIT1  
Execution Time: 00:51:00.007  
Number of Results: 9092  
UUT Result: Passed

Begin Sequence: MainSequence  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

DUT recap	
Status:	Done
TestResults/Data:	
Serial Number:	M086AB1000
Type Designator:	M4M20SEA
FW Version:	P2.6.14.0
Reset installation settings	
Status:	Passed
Module Time:	1.52225
Alarms Init	
Status:	Passed
Module Time:	10.4962

Begin Sequence: Alarms\_Init  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

COMM - Reset Alarms	
Status:	Passed
Module Time:	1.51236

Keyboard Go To Home	
Status:	Passed
Module Time:	2.57647
Keyboard Go To Home	
Status:	Skipped
Keyboard Reset Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Touch - Go Home	
Status:	Skipped
Touch - Reset Notifications	

Status:	Skipped
Touch - Go Home	
Status:	Skipped

### End Sequence: Alarms\_Init

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	1
Module Time:	125.171

**Begin Sequence: 1AlarmNSlots**  
**(C:\Users\itlavit1\OneDrive -**  
**ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)**

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.21873
COMM - Reset Slots	
Status:	Passed
Module Time:	0.771154
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09602
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.0959
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08896

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.872354
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0801269
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09698
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09097
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09407

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	2
Module Time:	120.877

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.861483
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0672473
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.1105
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08783
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09524

Check simple alarm - Omicron - No Alarm	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.05302
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0983638
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.1153
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08559
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10398

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	

Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	3
Module Time:	120.826

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.10145
COMM - Reset Slots	
Status:	Passed
Module Time:	0.12124
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09741
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08644
Keyboard Go To Home	
Status:	Passed
Module Time:	2.12055

Check simple alarm - Omicron - No Alarm	

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.843514
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0828546
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11354
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.1118
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09401

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

--	--

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

#### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	4
Module Time:	120.441

#### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.854979
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0698092
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09773
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.093
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10142



Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.850434
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0798467
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09852
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08664
Keyboard Go To Home	
Status:	Passed
Module Time:	2.12254

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	5
Module Time:	120.381

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlav1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.89957
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0649569
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.08907
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11668
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08255

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.832967
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0794286
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09466
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09318
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08339

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	6
Module Time:	120.339

**Begin Sequence: 1AlarmNSlots**  
**(C:\Users\itlavit1\OneDrive -**  
**ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)**

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.865527
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0730504
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09363
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08836
Keyboard Go To Home	

Status:	Passed
Module Time:	2.11384

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.878807
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0826523
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09654
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11493
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08896

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	7
Module Time:	120.21

**Begin Sequence: 1AlarmNSlots**  
**(C:\Users\itlavit1\OneDrive -**  
**ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)**

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.871182
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0667873
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11733
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09192

Keyboard Go To Home	
Status:	Passed
Module Time:	2.0859

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.843922
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0784761
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09347
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08681
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08167

Check simple alarm - Omicron - No Alarm	

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	8
Module Time:	120.451

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4M\PM4M-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8612
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0753523
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.0987
Keyboard Go Notifications	



Status:	Passed
Module Time:	2.09138
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08471

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.823852
COMM - Reset Slots	
Status:	Passed
Module Time:	0.083735
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11121
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08888
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08806

--	--

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	9
Module Time:	120.455

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.876779
COMM - Reset Slots	
Status:	Passed
Module Time:	0.064625
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10827

Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09158
Keyboard Go To Home	
Status:	Passed
Module Time:	2.11721

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.880128
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0933196
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10021
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.0821
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09294

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	10
Module Time:	136.847

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.823424
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0744855
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed

Module Time:	2.09014
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08183
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08866

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.939425
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0693695
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.099
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08178
Keyboard Go To Home	
Status:	Passed

Module Time:	2.1254
--------------	--------

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	11
Module Time:	125.998

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.902842
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0751527
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
---------------------	--

Status:	Passed
Module Time:	2.16418
Keyboard Go Notifications	
Status:	Passed
Module Time:	3.28145
Keyboard Go To Home	
Status:	Passed
Module Time:	2.20611

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.81497
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0505736
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.06974
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.06619
Keyboard Go To Home	

Status:	Passed
Module Time:	2.17411

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	12
Module Time:	119.787

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.793812
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0580912
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed



Keyboard Go To Home	
Status:	Passed
Module Time:	2.08183
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10584
Keyboard Go To Home	
Status:	Passed
Module Time:	2.06133

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.806672
COMM - Reset Slots	
Status:	Passed
Module Time:	0.049519
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.07097
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11656

Keyboard Go To Home	
Status:	Passed
Module Time:	2.07155

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	13
Module Time:	119.625

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.78868
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0608605
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.0625
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.06204
Keyboard Go To Home	
Status:	Passed
Module Time:	2.06424

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.81111
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0543623
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.07204
Keyboard Go Notifications	
Status:	Passed

Module Time:	2.06028
Keyboard Go To Home	
Status:	Passed
Module Time:	2.07716

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	14
Module Time:	122.311

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.810762
COMM - Reset Slots	
Status:	Passed
Module Time:	0.049406
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	

Status:	Passed
---------	--------

Keyboard Go To Home	
Status:	Passed
Module Time:	2.06678
Keyboard Go Notifications	
Status:	Passed
Module Time:	4.73375
Keyboard Go To Home	
Status:	Passed
Module Time:	2.06865

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.845758
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0524974
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.06706
Keyboard Go Notifications	

Status:	Passed
Module Time:	2.06097
Keyboard Go To Home	
Status:	Passed
Module Time:	2.05798

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

#### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	15
Module Time:	119.458

#### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.788611
COMM - Reset Slots	
Status:	Passed
Module Time:	0.051423
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.06019
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.05811
Keyboard Go To Home	
Status:	Passed
Module Time:	2.06042

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.791477
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0461862
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.06185

Keyboard Go Notifications	
Status:	Passed
Module Time:	2.15241
Keyboard Go To Home	
Status:	Passed
Module Time:	2.1001

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	16
Module Time:	119.936

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.808667
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0525476
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	



Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.07278
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.06532
Keyboard Go To Home	
Status:	Passed
Module Time:	2.11747

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.883412
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0818083
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed

Module Time:	2.09075
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10163
Keyboard Go To Home	
Status:	Passed
Module Time:	2.0828

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

#### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	17
Module Time:	120.444

#### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.829993
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0638685
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10062
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10117
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09313

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.883579
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0796683
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	

Status:	Passed
Module Time:	2.09384
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08898
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09582

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	18
Module Time:	120.405

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.848484
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0636271
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09098
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09049
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10205

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.891097
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0814571
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

--	--

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09654
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.0917
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10347

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	19
Module Time:	120.231

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM D-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.820696
COMM - Reset Slots	
Status:	Passed
Module Time:	0.132281
Check a simple alarm via Modbus	
Status:	Passed

Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09893
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09354
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09543

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.834013
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0843162
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.08971
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.0953
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09559

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

#### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	20
Module Time:	120.403

#### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.855499
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0704639
Check a simple alarm via Modbus	



Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09813
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08859
Keyboard Go To Home	
Status:	Passed
Module Time:	2.0927

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.891037
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0805348
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	

Status:	Passed
---------	--------

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09014
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.094
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09112

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	21
Module Time:	120.246

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.817533
COMM - Reset Slots	
Status:	Passed
Module Time:	0.111686

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09912
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11319
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10381

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.816368
COMM - Reset Slots	
Status:	Passed
Module Time:	0.116373
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09107
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09187
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09469

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	22
Module Time:	120.259

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.841285
COMM - Reset Slots	

Status:	Passed
Module Time:	0.0788499
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10928
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08542
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09431

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.818418
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0943641
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10664
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09626
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09054

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	23
Module Time:	120.488

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM D-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.911595

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0722212
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09548
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09053
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09527

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.879343
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0787531
Check a simple alarm via Modbus	
Status:	Passed

Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10112
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09873
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09378

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

**End Sequence: 1AlarmNSlots**

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	24
Module Time:	120.39

**Begin Sequence: 1AlarmNSlots**

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	



Status:	Passed
Module Time:	0.816734
COMM - Reset Slots	
Status:	Passed
Module Time:	0.0679114
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.1025
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08884
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10118

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.82164
COMM - Reset Slots	
Status:	Passed
Module Time:	0.136944
Check a simple alarm via Modbus	

Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10489
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08222
Keyboard Go To Home	
Status:	Passed
Module Time:	2.0824

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	25
Module Time:	120.213

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4M\PM4M-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1

COMM - Reset Alarms	
Status:	Passed
Module Time:	0.824256
COMM - Reset Slots	
Status:	Passed
Module Time:	0.112532
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10377
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09252
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10499

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.816079
COMM - Reset Slots	
Status:	Passed

Module Time:	0.083171
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09703
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09169
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09167

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

Alarms Dispose	
Status:	Passed
Module Time:	9.30219

Begin Sequence: Alarms\_Init  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

COMM - Reset Alarms	
Status:	Passed
Module Time:	0.842217

Keyboard Go To Home	
Status:	Passed
Module Time:	2.13436
Keyboard Go To Home	
Status:	Skipped
Keyboard Reset Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Touch - Go Home	
Status:	Skipped
Touch - Reset Notifications	
Status:	Skipped
Touch - Go Home	
Status:	Skipped

**End Sequence: Alarms\_Init**

**End Sequence: MainSequence**

**End UUT Report**

---