

UUT Report

Station ID: IT-W-7303101
Serial Number: NONE
Date: lunedì 29 maggio 2023
Time: 14:06:33
Operator: administrator
Execution Time: 2206.3658874 seconds
Number of Results: 7876
UUT Result: Passed

Begin Sequence: MainSequence

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

DUT recap	
Status:	Done
Serial Number:	M086AB1000
Type Designator:	M4M20SEA
FW Version:	P3.0.0.4
Reset installation settings	
Status:	Passed
Module Time:	0.3216107
Alarms Init	
Status:	Passed
Module Time:	7.7148375

Begin Sequence: Alarms_Init

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

COMM - Reset Alarms	
Status:	Passed
Module Time:	1.4475549

Keyboard Go To Home	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Keyboard Reset Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Touch - Go Home	
Status:	Skipped
Touch - Reset Notifications	
Status:	Skipped
Touch - Go Home	
Status:	Skipped

End Sequence: Alarms_Init

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	1

Module Time:

89.3989095

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8107199

COMM - Reset Slots	
Status:	Passed
Module Time:	0.2484465

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8123353

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0784414

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	2
Module Time:	87.4083056

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8199569

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0921402

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8186714

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0748701

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	3
Module Time:	87.5441459

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8271839

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0881341

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped

Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8267315

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0904827

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	4
Module Time:	87.3993236

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done

Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8098305

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0876414

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8108811

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0941218

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	5
Module Time:	87.3781101

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8104818

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0843011

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8127082

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0846434

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	

Status:	Skipped
---------	---------

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	6
Module Time:	87.3151899

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8055967

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0707082

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2

COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8085092

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0800048

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	7
Module Time:	87.3619995

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8078353
COMM - Reset Slots	

Status:	Passed
Module Time:	0.0835493

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8096053

COMM - Reset Slots	
Status:	Passed
Module Time:	0.084304

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	

Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	8
Module Time:	87.7307536

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.812209

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0726619

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.0400985

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1035004

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed

AlarmNumber [In]:	9
Module Time:	88.2413299

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.0777817

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1243351

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.0333636

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1043649

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	10
Module Time:	88.0394084

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.071407

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1040217

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.0573795

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1260928

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	11
Module Time:	87.2805254

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.814494

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0743199

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped

Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8176605

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0755949

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	12
Module Time:	87.3485929

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	

Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8190355

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0747564

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.826791

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0783088

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	13
Module Time:	87.4014219

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8213953

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0766737

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8300438

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0729869

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	

Status:	Skipped
---------	---------

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	14
Module Time:	87.4349369

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8249252

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0739272

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2

COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8231776

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0856931

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	15
Module Time:	87.4645108

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8303342
COMM - Reset Slots	

Status:	Passed
Module Time:	0.0868184

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8405303

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0874645

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	

Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	16
Module Time:	87.5829058

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8212137

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1208789

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8098916

COMM - Reset Slots	
Status:	Passed
Module Time:	0.1178306

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed

AlarmNumber [In]:	17
Module Time:	87.375178

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PM-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8100975

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0858631

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8093292

COMM - Reset Slots	
Status:	Passed
Module Time:	0.087609

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	18
Module Time:	87.3233901

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8063383

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0752855

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8144889

COMM - Reset Slots	
Status:	Passed
Module Time:	0.068244

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	19
Module Time:	87.2764717

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8114362

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0748881

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped

Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8100128

COMM - Reset Slots	
Status:	Passed
Module Time:	0.070812

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	20
Module Time:	87.3254205

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	

Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8076057

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0713328

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8243733

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0746629

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	21
Module Time:	87.3184677

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8179394

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0755559

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.809826

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0826717

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	

Status:	Skipped
---------	---------

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	22
Module Time:	87.3392297

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8203091

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0710296

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2

COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8143975

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0805151

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	23
Module Time:	87.2922518

Begin Sequence: 1AlarmNSlots
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8090683
COMM - Reset Slots	

Status:	Passed
Module Time:	0.0734307

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8123339

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0725431

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	

Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
AlarmNumber [In]:	24
Module Time:	87.374286

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8548162

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0726718

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8486797

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0792067

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed

AlarmNumber [In]:	25
Module Time:	87.3727993

Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8238825

COMM - Reset Slots	
Status:	Passed
Module Time:	0.0674726

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8210001

COMM - Reset Slots	
Status:	Passed
Module Time:	0.073395

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Skipped
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

End Sequence: 1AlarmNSlots

Alarms Dispose	
Status:	Passed
Module Time:	7.1761595

Begin Sequence: Alarms_Init
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

COMM - Reset Alarms	
Status:	Passed
Module Time:	0.8399864

Keyboard Go To Home	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Keyboard Reset Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Touch - Go Home	
Status:	Skipped
Touch - Reset Notifications	
Status:	Skipped

Status:	Skipped
Touch - Go Home	
Status:	Skipped

End Sequence: Alarms_Init

End Sequence: MainSequence

End UUT Report

