

Station ID:	IT-W-7303101
Serial Number:	NONE
Date:	mercoledì 1 febbraio 2023
Time:	16:28:24
Operator:	ITLAVIT1
Execution Time:	00:00:08.232
Number of Results:	535
UUT Result:	Passed

[illegible]

Status:	Skipped
Additional Results	
Status:	Skipped
input	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Communication	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Status Breaker	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Status Breaker	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Status Breaker	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Status Breaker	
Status:	Skipped
Reclosing attempts	
Status:	Skipped

Waiting time among reclosing	
Status:	Skipped
Neutralization time	
Status:	Skipped
Additional Results	
Status:	Skipped
Reclosing attempts	
Status:	Skipped
Waiting time among reclosing	
Status:	Skipped
Neutralization time	
Status:	Skipped
Additional Results	
Status:	Skipped
Tripped	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Tripped	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Tripped	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Tripped	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Tripped	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Peak Current Idle	
Status:	Skipped
Motor Torque Idle	
Status:	Skipped
Time to Max Torque Idle	
Status:	Skipped
Peak torque Toggle angle Idle	
Status:	Skipped
Close time Idle	
Status:	Skipped
Open time Idle	
Status:	Skipped
Peak Current Opening	
Status:	Skipped
Motor Torque Opening	

Status:	Skipped
Time to Max Torque Opening	
Status:	Skipped
Peak torque Toggle angle Opening	
Status:	Skipped
Close time Opening	
Status:	Skipped
Open time Opening	
Status:	Skipped
Peak Current Closing	
Status:	Skipped
Motor Torque Closing	
Status:	Skipped
Time to Max Torque Closing	
Status:	Skipped
Peak torque Toggle angle Closing	
Status:	Skipped
Close time Closing	
Status:	Skipped
Open time Closing	
Status:	Skipped
Total Number of maneuver	
Status:	Skipped
Total Number of closing maneuver	
Status:	Skipped
Maneuver attempt ongoing	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Maneuver attempt ongoing	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Maneuver attempt ongoing	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Maneuver attempt ongoing	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Total Number of maneuver	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped

Total Number of closing maneuver	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 2	

Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Output 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 1	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Input 2	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Diagnostic register	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Diagnostic register	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Diagnostic register	
Status:	Skipped
Pass/Fail Test	
Status:	Skipped
Product type number ID MOD	
Status:	Skipped

Product type number ID COMM	
Status:	Skipped
FW version MOD	
Status:	Skipped
FW version COMM	
Status:	Skipped
Modbus RTU parameter Slave Address	
Status:	Skipped
Modbus RTU parameter Baud Rate	
Status:	Skipped
Modbus RTU parameter Parity	
Status:	Skipped
LAST DEMANDED COMMAND FAILED PF	
Status:	Skipped
LAST DEMANDED COMMAND FAILED PF	
Status:	Skipped
LAST DEMANDED COMMAND FAILED PF	
Status:	Skipped
LAST DEMANDED COMMAND FAILED PF	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped
Additional Results	
Status:	Skipped

End Sequence: MainSequence

End UUT Report

