

UUT Report

Station ID: IT-W-7303101
Serial Number: NONE
Date: lunedì 30 ottobre 2023
Time: 10:59:19
Operator: administrator
Execution Time: 273.9892213 seconds
Number of Results: 250
UUT Result: Terminated
Product: MOD LV
Product type: MOD HV
Comm type: COMM1_RS485
Product FW Version: 56010805
Comm FW Version: 56010000

Begin Sequence: MainSequence
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Simultaneous trip_open	
Status:	Skipped
General and Architecture and LED	
Status:	Skipped
Input-Output	
Status:	Skipped
Power Outage	
Status:	Skipped
Motor Driver	
Status:	Skipped

Modbus Register check	
Status:	Terminated
Module Time:	268.2627189

Begin Sequence: Modbus Register check
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Internal communication failure	
Status:	Done
Register Value:	OK
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked during dead time.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed
input	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Communication	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
input	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Communication	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed

Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Input	
Status:	Done
Register Value:	Enable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input worked.
Status:	Passed
Communication	
Status:	Done
Register Value:	Enable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing and opening via input worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing and opening via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus worked.
Status:	Passed
Status Breaker	

Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Close
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Close
Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed

Tripped	
Status:	Done
Register Value:	Trip
Test Tripped	
Status:	Failed

Tripped	
Status:	Done
Register Value:	Trip
Test Tripped	
Status:	Passed
Tripped	
Status:	Done
Register Value:	Trip
Test Tripped	
Status:	Passed

Tripped	
Status:	Done
Register Value:	Trip
Test Tripped	
Status:	Failed

TIME Tripped	
Status:	Done
Time Tripped before:	000101000000

End Sequence: Modbus Register check

End Sequence: MainSequence

End UUT Report

