

UUT Report

Station ID: IT-W-7303101  
Serial Number: NONE  
Date: venerdì 24 marzo 2023  
Time: 15:46:55  
Operator: ITLAVIT1  
Execution Time: 00:53:58.006  
Number of Results: 9094  
UUT Result: Passed

Begin Sequence: MainSequence  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

DUT recap	
Status:	Done
TestResults/Data:	
Serial Number:	M086AB1000
Type Designator:	M4M20IMA
FW Version:	P3.0.0.3
Reset installation settings	
Status:	Passed
Module Time:	0.600054
Alarms Init	
Status:	Passed
Module Time:	10.6686

Begin Sequence: Alarms\_Init  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

COMM - Reset Alarms	
Status:	Passed
Module Time:	1.77302

Keyboard Go To Home	
Status:	Passed
Module Time:	2.41272
Keyboard Go To Home	
Status:	Skipped
Keyboard Reset Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Touch - Go Home	
Status:	Skipped
Touch - Reset Notifications	

Status:	Skipped
Touch - Go Home	
Status:	Skipped

### End Sequence: Alarms\_Init

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	1
Module Time:	235.178

**Begin Sequence: 1AlarmNSlots**  
**(C:\Users\itlavit1\OneDrive -**  
**ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)**

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	4.93427
COMM - Reset Slots	
Status:	Passed
Module Time:	2.82689
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10629
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.0922
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09008

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.80907
COMM - Reset Slots	
Status:	Passed
Module Time:	0.155543
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10233
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10196
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10584

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed

Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	2
Module Time:	123.447

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMd-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.71898
COMM - Reset Slots	
Status:	Passed
Module Time:	0.133969
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11189
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09643
Keyboard Go To Home	
Status:	Passed
Module Time:	2.12421

Check simple alarm - Omicron - No Alarm	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.71409
COMM - Reset Slots	
Status:	Passed
Module Time:	0.157964
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10853
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12257
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09065

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed

Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	3
Module Time:	122.855

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.59754
COMM - Reset Slots	
Status:	Passed
Module Time:	0.205902
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.1089
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.103
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09149

Check simple alarm - Omicron - No Alarm	

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.6939
COMM - Reset Slots	
Status:	Passed
Module Time:	0.127525
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09527
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10966
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08977

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

--	--

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	4
Module Time:	122.904

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.70474
COMM - Reset Slots	
Status:	Passed
Module Time:	0.199157
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11037
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09832
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08853



Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.70277
COMM - Reset Slots	
Status:	Passed
Module Time:	0.128704
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09956
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11471
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09054

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	5
Module Time:	122.955

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.66251
COMM - Reset Slots	
Status:	Passed
Module Time:	0.163902
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09833
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11651
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09735

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.59117
COMM - Reset Slots	
Status:	Passed
Module Time:	0.115214
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10339
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11992
Keyboard Go To Home	
Status:	Passed
Module Time:	2.0946

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	6
Module Time:	123.283

**Begin Sequence: 1AlarmNSlots**  
**(C:\Users\itlavit1\OneDrive -**  
**ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)**

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.73499
COMM - Reset Slots	
Status:	Passed
Module Time:	0.184727
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10558
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09067
Keyboard Go To Home	

Status:	Passed
Module Time:	2.09227

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.68352
COMM - Reset Slots	
Status:	Passed
Module Time:	0.122758
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10267
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12129
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09047

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	7
Module Time:	124.254

**Begin Sequence: 1AlarmNSlots**  
**(C:\Users\itlavit1\OneDrive -**  
**ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)**

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	2.17458
COMM - Reset Slots	
Status:	Passed
Module Time:	0.165306
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10621
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08772

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11459

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	2.05107
COMM - Reset Slots	
Status:	Passed
Module Time:	0.16915
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.0984
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09139
Keyboard Go To Home	
Status:	Passed
Module Time:	2.12107

Check simple alarm - Omicron - No Alarm	

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	8
Module Time:	148.323

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4M\PM4M-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.76641
COMM - Reset Slots	
Status:	Passed
Module Time:	0.163164
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10076
Keyboard Go Notifications	



Status:	Passed
Module Time:	2.09295
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09122

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.74294
COMM - Reset Slots	
Status:	Passed
Module Time:	0.203917
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10371
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09458
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08949

--	--

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	9
Module Time:	122.879

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.62005
COMM - Reset Slots	
Status:	Passed
Module Time:	0.184972
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10689

Keyboard Go Notifications	
Status:	Passed
Module Time:	2.096
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09221

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.6226
COMM - Reset Slots	
Status:	Passed
Module Time:	0.121468
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10989
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12732
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09139

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	10
Module Time:	123.041

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.69958
COMM - Reset Slots	
Status:	Passed
Module Time:	0.152578
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed

Module Time:	2.09209
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10348
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08941

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.67438
COMM - Reset Slots	
Status:	Passed
Module Time:	0.120795
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09911
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12272
Keyboard Go To Home	
Status:	Passed

Module Time:	2.08888
--------------	---------

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	11
Module Time:	122.887

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.52858
COMM - Reset Slots	
Status:	Passed
Module Time:	0.123752
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
---------------------	--

Status:	Passed
Module Time:	2.09882
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09748
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09966

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.56476
COMM - Reset Slots	
Status:	Passed
Module Time:	0.115306
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10141
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11997
Keyboard Go To Home	

Status:	Passed
Module Time:	2.09979

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	12
Module Time:	123.038

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.55865
COMM - Reset Slots	
Status:	Passed
Module Time:	0.107229
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed



Keyboard Go To Home	
Status:	Passed
Module Time:	2.10616
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08446
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09642

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.72245
COMM - Reset Slots	
Status:	Passed
Module Time:	0.123616
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10657
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12476

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10048

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	13
Module Time:	122.786

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.59482
COMM - Reset Slots	
Status:	Passed
Module Time:	0.1969
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09885
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.1075
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09409

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.61217
COMM - Reset Slots	
Status:	Passed
Module Time:	0.132895
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.12534
Keyboard Go Notifications	
Status:	Passed

Module Time:	2.11948
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09114

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	14
Module Time:	123.092

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.64621
COMM - Reset Slots	
Status:	Passed
Module Time:	0.212504
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	

Status:	Passed
---------	--------

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11792
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09333
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09067

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.65595
COMM - Reset Slots	
Status:	Passed
Module Time:	0.17797
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.09647
Keyboard Go Notifications	

Status:	Passed
Module Time:	2.10969
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09022

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

#### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	15
Module Time:	122.58

#### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.54064
COMM - Reset Slots	
Status:	Passed
Module Time:	0.119779
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed

Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11332
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12439
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09078

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.64088
COMM - Reset Slots	
Status:	Passed
Module Time:	0.1322
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10987

Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11171
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09578

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	16
Module Time:	122.985

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.63
COMM - Reset Slots	
Status:	Passed
Module Time:	0.126414
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	



Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10978
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11569
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08497

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.71038
COMM - Reset Slots	
Status:	Passed
Module Time:	0.118919
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed

Module Time:	2.09728
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11189
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08763

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	17
Module Time:	122.753

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.61902
COMM - Reset Slots	
Status:	Passed
Module Time:	0.204619
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10777
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09575
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09605

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.53847
COMM - Reset Slots	
Status:	Passed
Module Time:	0.125534
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	

Status:	Passed
Module Time:	2.09449
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.13466
Keyboard Go To Home	
Status:	Passed
Module Time:	2.0982

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	18
Module Time:	123.102

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.67813
COMM - Reset Slots	
Status:	Passed
Module Time:	0.252272
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	

Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10698
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09168
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08741

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.70675
COMM - Reset Slots	
Status:	Passed
Module Time:	0.12632
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

--	--

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10328
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12004
Keyboard Go To Home	
Status:	Passed
Module Time:	2.08962

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	19
Module Time:	122.964

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -

ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM D-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.709
COMM - Reset Slots	
Status:	Passed
Module Time:	0.122631
Check a simple alarm via Modbus	
Status:	Passed

Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11288
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.09698
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09367

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.56368
COMM - Reset Slots	
Status:	Passed
Module Time:	0.124511
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11064
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12532
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09248

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	20
Module Time:	122.906

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.60862
COMM - Reset Slots	
Status:	Passed
Module Time:	0.156019
Check a simple alarm via Modbus	



Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10127
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11372
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09297

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.54937
COMM - Reset Slots	
Status:	Passed
Module Time:	0.123643
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	

Status:	Passed
---------	--------

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10174
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11458
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09021

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	21
Module Time:	123.178

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.67339
COMM - Reset Slots	
Status:	Passed
Module Time:	0.201104

Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10352
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.10325
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09519

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.64149
COMM - Reset Slots	
Status:	Passed
Module Time:	0.115298
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	

Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10266
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12046
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09514

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	22
Module Time:	123.175

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.61703
COMM - Reset Slots	

Status:	Passed
Module Time:	0.170237
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.1005
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12015
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09128

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.69115
COMM - Reset Slots	
Status:	Passed
Module Time:	0.12051
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed

Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.12095
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.1318
Keyboard Go To Home	
Status:	Passed
Module Time:	2.0933

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	23
Module Time:	123.037

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM D-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.88357

COMM - Reset Slots	
Status:	Passed
Module Time:	0.147229
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10173
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.08579
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09429

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.63967
COMM - Reset Slots	
Status:	Passed
Module Time:	0.172153
Check a simple alarm via Modbus	
Status:	Passed

Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10315
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11987
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09461

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	24
Module Time:	122.519

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PMD-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1
COMM - Reset Alarms	



Status:	Passed
Module Time:	1.48897
COMM - Reset Slots	
Status:	Passed
Module Time:	0.150198
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10476
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11178
Keyboard Go To Home	
Status:	Passed
Module Time:	2.10056

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.57482
COMM - Reset Slots	
Status:	Passed
Module Time:	0.122311
Check a simple alarm via Modbus	

Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.11188
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11357
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09377

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

### End Sequence: 1AlarmNSlots

1 Alarm N Slots	
Status:	Passed
Parameters	
AlarmNumber:	25
Module Time:	123.266

### Begin Sequence: 1AlarmNSlots

(C:\Users\itlavit1\OneDrive -  
ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM4M\PM4M-4444.seq)

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	1

COMM - Reset Alarms	
Status:	Passed
Module Time:	1.60826
COMM - Reset Slots	
Status:	Passed
Module Time:	0.205826
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.10438
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.12045
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09434

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

Additional Results	
Status:	Done
TestResults/Data:	
Slot number:	2
COMM - Reset Alarms	
Status:	Passed
Module Time:	1.66071
COMM - Reset Slots	
Status:	Passed

Module Time:	0.11988
Check a simple alarm via Modbus	
Status:	Passed
Check simple alarm - Omicron - Alarm Triggered	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - Alarm Triggered	
Status:	Passed

Keyboard Go To Home	
Status:	Passed
Module Time:	2.12571
Keyboard Go Notifications	
Status:	Passed
Module Time:	2.11306
Keyboard Go To Home	
Status:	Passed
Module Time:	2.09354

Check simple alarm - Omicron - No Alarm	
Status:	Passed
Check a simple alarm via Modbus flags	
Status:	Passed
Check simple alarm - Modbus - IO - No Alarm	
Status:	Passed

Image ROI Matching - Alarm	
Status:	Failed
Keyboard Go Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped

**End Sequence: 1AlarmNSlots**

Alarms Dispose	
Status:	Passed
Module Time:	10.3296

**Begin Sequence: Alarms\_Init**  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\M4M\PM-4444.seq)

COMM - Reset Alarms	
Status:	Passed
Module Time:	1.76039



Keyboard Go To Home	
Status:	Passed
Module Time:	2.09749
Keyboard Go To Home	
Status:	Skipped
Keyboard Reset Notifications	
Status:	Skipped
Keyboard Go To Home	
Status:	Skipped
Touch - Go Home	
Status:	Skipped
Touch - Reset Notifications	
Status:	Skipped
Touch - Go Home	
Status:	Skipped

**End Sequence: Alarms\_Init**

**End Sequence: MainSequence**

**End UUT Report**

---