

UUT Report

Station ID: IT-W-7303101
Serial Number: NONE
Date: martedì 23 maggio 2023
Time: 10:58:27
Operator: administrator
Execution Time: 1714.1380651 seconds
Number of Results: 1536
UUT Result: Passed
Serial Number: 4294967295
Type Designator: B3-D4MB-111A
FW Version: 0.16.1
Power Supply: Zera
Energy Measurement: ACTIVE_ENERGY



Begin Sequence: MainSequence
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\EQ Meter\New Sequences\Energy Accuracy.seq)

DUT info	
Status:	Done
Serial Number:	4294967295
Type Designator:	B3-D4MB-111A
FW Version:	0.16.1

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	48.8726916

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.2475734

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.2443266

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.0580416

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.7584554

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.0544054

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	45.9566543

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	41.1199324

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	42.7231364

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.4635691

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.2596739

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.9710017

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.9609523

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.7708963

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
---------------	--

Status:	Passed
Module Time:	46.6604882

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.2453624

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	41.5240185

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	43.2268952

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	49.4714846

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.1638901

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.5494993

End Seqy Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.9741133

End Seqy Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.54841

End Seqy Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.2576778

End Seqy Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	46.4539182

End Seqy Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	45.1512361

End Seqy Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	41.0190403

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	45.7494158

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.2484112

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.0585272

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.2561709

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	44.9540648

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	43.744451

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	45.3513258

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.562312

End Sequence: Energy_Accuracy

Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	47.1618429

End Sequence: Energy_Accuracy


Begin Sequence: Energy_Accuracy
(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\Utilities\CommonUtilitySequencesEqRed.seq)

Zera Accuracy	
Status:	Passed
Module Time:	45.0291075

End Sequence: Energy_Accuracy

Energy Error graph - LOG	
Status:	Done
Legend:	The brown line is the error on the Energy measurement. The blue line is the upper limit of the allowed band. The orange line is the lower limit of the allowed band.
Graph[0..2]	

[0..36]:



End Sequence: MainSequence

End UUT Report

