

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

Product:

Product type:

Comm type:

Product FW Version:

Comm FW Version:

Failure Chain:

IT-W-7303101

NONE

venerdi 27 ottobre 2023

15:07:54

administrator

179.1572993 seconds

126

Failed

MOD LV

MOD HV

COMM1\_RS485

56010805

56010000

Step	Sequence	Sequence File
<a href="#">Check LED Status</a>	General and Architecture and LED	General_test.seq
<a href="#">General and Architecture and LED</a>	MainSequence	General_test.seq

Begin Sequence: MainSequence  
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Simultaneous trip_open	
Status:	Skipped
General and Architecture and LED	
Status:	Failed
Module Time:	168.8691117

Begin Sequence: General and Architecture and LED  
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	

Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in both active and close configurations.
Status:	Passed

Check LED Status	
Status:	Failed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Failed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Check LED Status	
Status:	Failed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Failed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed

End Sequence: General and Architecture and LED

Input-Output	
Status:	Skipped
Power Outage	
Status:	Skipped
Motor Driver	
Status:	Skipped

Modbus Register check	
Status:	Skipped
Modbus settings check	
Status:	Skipped
COMM LED & Button	
Status:	Skipped
Firmware Upgrade	
Status:	Skipped

End Sequence: MainSequence

End UUT Report

