

BITWIG STUDIO CONTROLLER EXTENSION

# ICON **PLATFORM M+**



# ICON PLATFORM M+

## Pan/Device Remote Control

Mixer mode: Turn the encoders to control the pan position of a track.

Device mode: Turn the encoders to control the eight remote control parameters of the currently selected device, track, or the project remotes.

Press the encoders to return to the default value of the parameter.

## Mixer/Device Mode

Press Mixer to toggle between Mixer and Device mode.

## Restore Automation Control

Press Read to restore automation control. This button will only light up when existing automation data is manually overwritten. Pressing Read will return to reading the automation data.

## Automation Write

Press Write to toggle automation write in the arranger to record automation data when using the encoders or faders. When touch automation mode is active, the faders will only write automation data when actually touched.

## Chan < >

Moves the track selection by one track.

## Bank << >>

Moves the track selection in banks of eight.

## Flip

Pressing Bank << and Trans << at the same time activates Flip mode, which swaps the parameters of the eight encoders and faders.

## Transport Section

Use the buttons to control the transport section of Bitwig Studio.

## Zoom

Activate the horizontal or vertical zoom button to change the zoom level with the jog wheel

## Playhead Position/Zoom

Turn the jog wheel to move the playhead.

Press the jog wheel to toggle between coarse and fine resolution.

Turn the jog wheel to change zoom level when zoom buttons are activated.

Track Volume  
Master Volume

Track Select  
Mute  
Solo  
Record Enable



# ICON PLATFORM M+

## Setup and Options

### Setup

The Platform M+ should be detected and set up automatically when it is connected. If you add the controller manually, make sure the correct MIDI ports are selected:\*

### Mac/Windows:

In: Platform M+ V2.15  
Out: Platform M+ V2.15

### Linux:

In: Platform M+ V2.15 MIDI 1  
Out: Platform M+ V2.15 MIDI 1


*\*The number 2.15 reflects the firmware version and is subject to change.*

### Options

If "Follow Selected Track" is activated in the controller options, the hardware will follow the track selection made by mouse or keyboard in the Bitwig Studio GUI.

### Controller Status Section

When the Platform M+ is recognized by Bitwig Studio, a small keyboard icon appears in the top right corner of the application window. Clicking on this icon will open the controller status window.



In the middle section the current knob assignment is shown. Pressing one of the pin icons lets you permanently assign the controls to certain parameters. For more information please read the Bitwig Studio user guide.