



ROMWBW

Hardware

Version 3.5

Updated 31 Mar 2025

RetroBrew Computers Group
www.retrobrewcomputers.org

Wayne Warthen
wwarthen@gmail.com

Contents

1	Supported Hardware Platforms	1
2	Platform Configurations	4
2.1	RetroBrew Z80 SBC	4
2.2	RetroBrew Z80 SimH	6
2.3	RetroBrew N8 Z180 SBC	7
2.4	Zeta Z80 SBC	8
2.5	Zeta V2 Z80 SBC	9
2.6	Mark IV Z180 SBC	10
2.7	RCBus Z80 CPU Module	11
2.8	RCBus Z180 CPU Module	13
2.9	RCBus Z280 CPU Module	16
2.10	RCBus eZ80 CPU Module	18
2.11	Easy Z80 SBC	19
2.12	Tiny Z80 SBC	21
2.13	Z80-512K CPU/RAM/ROM Module	22
2.14	Small Computer SC126 Z180 SBC	23
2.15	Small Computer SC130 Z180 SBC	25
2.16	Small Computer SC131 Z180 Pocket Comp	27
2.17	Small Computer SC140 Z180 CPU Module	28
2.18	Small Computer SC503 Z180 CPU Module	30
2.19	Small Computer SC700 Z180 CPU Module	32
2.20	Dyno Z180 SBC	34
2.21	Nhyodyne Z80 MBC	35
2.22	Rhyophyre Z180 SBC	37
2.23	Z80 ZRC CPU Module	38
2.24	Z80 ZRC512 CPU Module	41
2.25	Z80 EaZy80-512 CPU Module	43
2.26	Z80 K80W CPU Module	45
2.27	Z180 Z1RCC CPU Module	47
2.28	Z280 ZZRCC CPU Module	49

2.29	Z280 ZZ80MB SBC	52
2.30	Z80-Retro SBC	54
2.31	S100 Computers Z180	55
2.32	Duodyne Z80 System	56
2.33	Heath H8 Z80 System	58
2.34	EP Mini-ITX Z180	59
2.35	NABU w/ RomWBW Option Board	60
2.36	S100 FPGA Z80	61
2.37	Genesis STD Z180	61
3	Device Drivers	63
3.1	Character	63
3.2	Disk	64
3.3	Video	64
3.4	Keyboard	65
3.5	Audio	65
3.6	RTC (RealTime Clock)	65
3.7	DsKy (DiSplay KeYpad)	66
3.8	System	66
4	UNA Hardware BIOS	67
4.1	UNA Usage Notes	68
5	Errata	69

Chapter 1

Supported Hardware Platforms

This section contains a summary of the system configuration target for each of the pre-built ROM images included in the RomWBW distribution.

It is intended to help you select the correct ROM image and understand the basic hardware components supported. Detailed hardware system configuration information should be obtained from your system provider/designer.

The table below summarizes the hardware platforms currently supported by RomWBW along with the standard pre-built ROM image(s).

Description	Bus	ROM Image File	Baud Rate
RetroBrew Z80 SBC ¹	ECB	SBC_std.rom	38400
RetroBrew Z80 SimH ¹	-	SBC_simh.rom	38400
RetroBrew N8 Z180 SBC ¹ (date >= 2312)	ECB	N8_std.rom	38400
Zeta Z80 SBC ² , ParPortProp	-	ZETA_std.rom	38400
Zeta V2 Z80 SBC ² , ParPortProp	-	ZETA2_std.rom	38400
Mark IV Z180 SBC ³	ECB	MK4_std.rom	38400
RCBus Z80 CPU Module ⁴ , 512K RAM/ROM	RCBus	RCZ80_std.rom	115200
RCBus Z80 CPU Module ⁴ , 512K w/KIO	RCBus	RCZ80_kio_std.rom	115200
RCBus Z180 CPU Module ⁴ w/ ext banking	RCBus	RCZ180_ext_std.rom	115200
RCBus Z180 CPU Module ⁴ w/ native banking	RCBus	RCZ180_nat_std.rom	115200
RCBus Z280 CPU Module ⁴ w/ ext banking	RCBus	RCZ280_ext_std.rom	115200
RCBus Z280 CPU Module ⁴ w/ native banking	RCBus	RCZ280_nat_std.rom	115200
RCBus eZ80 CPU Module ¹³ , 512K RAM/ROM	RCBus	RCEZ80_std.rom	115200
Easy Z80 SBC ²	RCBus	RCZ80_easy_std.rom	115200
Tiny Z80 SBC ²	RCBus	RCZ80_tiny_std.rom	115200

Description	Bus	ROM Image File	Baud Rate
Z80-512K CPU/RAM/ROM Module ²	RCBus	RCZ80_skz_std.rom	115200
Small Computer SC126 Z180 SBC ⁵	BP80	SCZ180_sc126_std.rom	115200
Small Computer SC130 Z180 SBC ⁵	RCBus	SCZ180_sc130_std.rom	115200
Small Computer SC131 Z180 Pocket Comp ⁵	-	SCZ180_sc131_std.rom	115200
Small Computer SC140 Z180 CPU Module ⁵	Z50	SCZ180_sc140_std.rom	115200
Small Computer SC503 Z180 CPU Module ⁵	Z50	SCZ180_sc503_std.rom	115200
Small Computer SC700 Z180 CPU Module ⁵	RCBus	SCZ180_sc700_std.rom	115200
Dyno Z180 SBC ⁶	Dyno	DYNO_std.rom	38400
Nhyodyne Z80 MBC ¹	MBC	MBC_std.rom	38400
Rhyophyre Z180 SBC ¹	-	RPH_std.rom	38400
Z80 ZRC CPU Module ⁷	RCBus	RCZ80_zrc_std.rom	115200
Z80 ZRC CPU Module ⁷ ROMless	RCBus	RCZ80_zrc_ram_std.rom	115200
Z80 ZRC512 CPU Module ⁷	RCBus	RCZ80_zrc512_std.rom	115200
Z80 EaZy80-512 CPU Module ⁷	RCBus	RCZ80_ez512_std.rom	115200
Z80 K80W CPU Module ⁷	RCBus	RCZ80_k8w_std.rom	115200
Z180 Z1RCC CPU Module ⁷	RCBus	RCZ180_z1rcc_std.rom	115200
Z280 ZZRCC CPU Module ⁷	RCBus	RCZ280_zzrcc_std.rom	115200
Z280 ZZRCC CPU Module ⁷ ROMless	RCBus	RCZ280_zzrcc_ram_std.rom	115200
Z280 ZZ80MB SBC ⁷	RCBus	RCZ280_zz80mb_std.rom	115200
Z80-Retro SBC ⁸	-	Z80RETRO_std.rom	38400
S100 Computers Z180 ⁹	S100	S100_std.rom	57600
Duodyne Z80 System ¹	Duo	DUO_std.rom	38400
Heath H8 Z80 System ¹⁰	H8	HEATH_std.rom	115200
EP Mini-ITX Z180 ¹¹	RCBus?	EPITX_std.rom	115200
NABU w/ RomWBW Option Board ¹⁰	NABU	NABU_std.rom	115200
S100 FPGA Z80 ⁹	S100	FZ80_std.rom	9600
Genesis STD Z180 ¹²	STD	GMZ180_std.rom	115200

¹Designed by Andrew Lynch²Designed by Sergey Kiselev³Designed by John Coffman⁴RCBus compliant (multiple products/designers)⁵Designed by Stephen Cousins⁶Designed by Steve Garcia⁷Designed by Bill Shen⁸Designed by Peter Wilson⁹Designed by John Monahan

¹⁰Designed by Les Bird

¹¹Designed by Alan Cox

¹²Designed by Doug Jackson

¹³Designed by Dean Netherton

RCBus refers to Spencer Owen's RC2014 bus specification and derivatives including RC26, RC40, RC80, and BP80.

The RCBus Z180 & Z280 require a separate RAM/ROM memory module. There are two types of these modules and you must pick the correct ROM for your type of memory module. The first option is the same as the 512K RAM/ROM module for RC/BP80 Bus. This is called external ("ext") because the bank switching is performed externally from the CPU. The second type of RAM/ROM module has no bank switching logic – this is called native ("nat") because the CPU itself provides the bank switching logic. Only Z180 and Z280 CPUs have the ability to do bank switching in the CPU, so the ext/nat selection only applies to them. Z80 CPUs have no built-in bank switching logic, so they are always configured for external bank switching.

The standard ROM images will detect and install support for certain devices and peripherals that are on-board or frequently used with each platform. If the device or peripheral is not detected at boot, the ROM will simply bypass support appropriately.

In some cases, support for multiple hardware components with potentially conflicting resource usage are handled by a single ROM image. It is up to the user to ensure that no conflicting hardware is in use.

All pre-built ROM images are pure binary files (they are not "hex" files). They are intended to be programmed starting at the very start of the ROM chip (address 0). Most of the pre-built images are 512KB in size. If your system utilizes a larger ROM, you can just program the image into the first 512KB of the ROM for now.

Chapter 2

Platform Configurations

2.1 RetroBrew Z80 SBC

ROM Image File: SBC_std.rom

Default CPU Speed	8.000 MHz
Interrupts	None
System Timer	None
Serial Default	38400 Baud
Memory Manager	SBC
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=112
- UART: MODE=SBC, IO=104
- UART: MODE=CAS, IO=128
- UART: MODE=MFP, IO=104
- UART: MODE=4UART, IO=192
- UART: MODE=4UART, IO=200
- UART: MODE=4UART, IO=208
- UART: MODE=4UART, IO=216
- SIO MODE=ZP, IO=176, CHANNEL A
- SIO MODE=ZP, IO=176, CHANNEL B
- VGA: IO=224, KBD MODE=PS/2, KBD IO=224

- CVDU: MODE=ECB, IO=224, KBD MODE=PS/2, KBD IO=226
- CVDU occupies 905 bytes.
- KBD: ENABLED
- PRP: IO=168
- PRPCON: ENABLED
- PRPSD: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=DIO, IO=54, DRIVE 0, TYPE=3.5" HD
- FD: MODE=DIO, IO=54, DRIVE 1, TYPE=3.5" HD
- PPIDE: IO=96, MASTER
- PPIDE: IO=96, SLAVE

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.2 RetroBrew Z80 SimH

ROM Image File: SBC_simh.rom

Default CPU Speed	8.000 MHz
Interrupts	Mode 1
System Timer	SimH
Serial Default	38400 Baud
Memory Manager	SBC
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- SIMRTC: IO=254
- UART: MODE=SBC, IO=104
- UART: MODE=CAS, IO=128
- UART: MODE=MFP, IO=104
- UART: MODE=4UART, IO=192
- UART: MODE=4UART, IO=200
- UART: MODE=4UART, IO=208
- UART: MODE=4UART, IO=216
- SIO MODE=ZP, IO=176, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=ZP, IO=176, CHANNEL B, INTERRUPTS ENABLED
- FONTS occupy 0 bytes.
- MD: TYPE=RAM
- MD: TYPE=ROM
- HDSK: IO=253, DEVICE COUNT=2

Notes:

- Image for SimH emulator
- CPU speed and Serial configuration not relevant in emulator

2.3 RetroBrew N8 Z180 SBC

ROM Image File: N8_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	38400 Baud
Memory Manager	N8
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=136
- ASCI: IO=64, INTERRUPTS ENABLED
- ASCI: IO=65, INTERRUPTS ENABLED
- UART: MODE=CAS, IO=128
- UART: MODE=4UART, IO=192
- UART: MODE=4UART, IO=200
- UART: MODE=4UART, IO=208
- UART: MODE=4UART, IO=216
- TMS: MODE=N8, IO=152
- PPK: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=N8, IO=140, DRIVE 0, TYPE=3.5" HD
- FD: MODE=N8, IO=140, DRIVE 1, TYPE=3.5" HD
- SD: MODE=CSIO, IO=136, UNITS=1
- AY38910: MODE=N8, IO=156, CLOCK=1789772 HZ

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present
- SD Card interface is configured for CSIO (N8 date code >= 2312)

2.4 Zeta Z80 SBC

ROM Image File: ZETA_std.rom

Default CPU Speed	8.000 MHz
Interrupts	None
System Timer	None
Serial Default	38400 Baud
Memory Manager	SBC
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=112
- UART: MODE=SBC, IO=104
- PPP: IO=96
- PPPCON: ENABLED
- PPPSD: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=DIO, IO=54, DRIVE 0, TYPE=3.5" HD

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present
- If ParPortProp is installed, initial console output is determined by JP1:
 - Shorted: console to on-board serial port
 - Open: console to ParPortProp video and keyboard

2.5 Zeta V2 Z80 SBC

ROM Image File: ZETA2_std.rom

Default CPU Speed	8.000 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	38400 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=112
- UART: MODE=SBC, IO=104
- PPP: IO=96
- PPPCON: ENABLED
- PPPSD: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=ZETA2, IO=48, DRIVE 0, TYPE=3.5" HD
- CTC: IO=32, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present
- If ParPortProp is installed, initial console output is determined by JP1:
 - Shorted: console to on-board serial port
 - Open: console to ParPortProp video and keyboard

2.6 Mark IV Z180 SBC

ROM Image File: MK4_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	38400 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=138
- ASCI: IO=64, INTERRUPTS ENABLED
- ASCI: IO=65, INTERRUPTS ENABLED
- UART: MODE=CAS, IO=128
- UART: MODE=MFP, IO=104
- UART: MODE=4UART, IO=192
- UART: MODE=4UART, IO=200
- UART: MODE=4UART, IO=208
- UART: MODE=4UART, IO=216
- VGA: IO=224, KBD MODE=PS/2, KBD IO=224
- CVDU: MODE=ECB, IO=224, KBD MODE=PS/2, KBD IO=226
- KBD: ENABLED
- PRP: IO=168
- PRPCON: ENABLED
- PRPSD: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=DIDE, IO=42, DRIVE 0, TYPE=3.5" HD
- FD: MODE=DIDE, IO=42, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=MK4, IO=128, MASTER
- IDE: MODE=MK4, IO=128, SLAVE
- SD: MODE=MK4, IO=137, UNITS=1

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.7 RCBus Z80 CPU Module

ROM Image File: RCZ80_std.rom

Default CPU Speed	7.372 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

ROM Image File: RCZ80_kio_std.rom

Default CPU Speed	7.372 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=STD, IO=136, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=136, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=132, TIMER MODE=TIMER/16, DIVISOR=9216, HI=256, LO=36, INTERRUPTS ENABLED

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present
- SIO Serial baud rate managed by CTC

2.8 RCBus Z180 CPU Module

ROM Image File: RCZ180_ext_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- For use with Z2 bank switched memory board (Z2 external memory management)
- CPU speed will be dynamically measured at startup if DSRTC is present

ROM Image File: RCZ180_nat_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- For use with linear memory board (Z180 native memory management)
- CPU speed will be dynamically measured at startup if DSRTC is present

2.9 RCBus Z280 CPU Module

ROM Image File: RCZ280_ext_std.rom

Default CPU Speed	6.000 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- Z2U: IO=16
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- ACIA: IO=128, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- For use with Z2 bank switched memory board (Z2 external memory management)

ROM Image File: RCZ280_nat_std.rom

Default CPU Speed	6.000 MHz
Interrupts	Mode 3
System Timer	Z280
Serial Default	115200 Baud
Memory Manager	Z280
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- Z2U: IO=16, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- For use with linear memory board (Z280 native memory management)

2.10 RCBus eZ80 CPU Module

ROM Image File: RCEZ80_std.rom

Default CPU Speed	20.000 MHz
Interrupts	Mode 1
System Timer	EZ80
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- LCD: IO=218
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- EZ80: CPU DRIVER
- EZ80: SYS TIMER DRIVER
- EZ80: RTC DRIVER
- EZ80: UART DRIVER

Notes:

2.11 Easy Z80 SBC

ROM Image File: RCZ80_easy_std.rom

Default CPU Speed	10.000 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- INTRTC: ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=STD, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.12 Tiny Z80 SBC

ROM Image File: RCZ80_tiny_std.rom

Default CPU Speed	16.000 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=STD, IO=24, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=24, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=144, MASTER
- IDE: MODE=RC, IO=144, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=16, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.13 Z80-512K CPU/RAM/ROM Module

ROM Image File: RCZ80_skz_std.rom

Default CPU Speed	7.372 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.14 Small Computer SC126 Z180 SBC

ROM Image File: SCZ180_sc126_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=13, SWIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=SC, IO=12, UNITS=1
- AY38910: MODE=RCZ180, IO=104, CLOCK=1789772 HZ

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present
- When disabled, watchdog requires /IM to be pulsed. If an RCBus module holds the CPU in WAIT for more than this, the watchdog will fire when disabled with random consequences. The Pico SD does this at power-on.

2.15 Small Computer SC130 Z180 SBC

ROM Image File: SCZ180_sc130_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=SC, IO=12, UNITS=1
- AY38910: MODE=RCZ180, IO=104, CLOCK=1789772 HZ

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.16 Small Computer SC131 Z180 Pocket Comp

ROM Image File: SCZ180_sc131_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- SD: MODE=SC, IO=12, UNITS=1

Notes:

2.17 Small Computer SC140 Z180 CPU Module

ROM Image File: SCZ180_sc140_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=160, SWIO=160
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=144, MASTER
- IDE: MODE=RC, IO=144, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=SC, IO=12, UNITS=1

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.18 Small Computer SC503 Z180 CPU Module

ROM Image File: SCZ180_sc503_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=160, SWIO=160
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=144, MASTER
- IDE: MODE=RC, IO=144, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=SC, IO=12, UNITS=1

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.19 Small Computer SC700 Z180 CPU Module

ROM Image File: SCZ180_sc700_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=SC, IO=12, UNITS=1
- AY38910: MODE=RCZ180, IO=104, CLOCK=1789772 HZ

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.20 Dyno Z180 SBC

ROM Image File: DYNO_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	38400 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- BQRTC: IO=80
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=DYNO, IO=132, DRIVE 0, TYPE=3.5" HD
- FD: MODE=DYNO, IO=132, DRIVE 1, TYPE=3.5" HD
- PPIDE: IO=76, MASTER
- PPIDE: IO=76, SLAVE

Notes:

2.21 Nhyodyne Z80 MBC

ROM Image File: MBC_std.rom

Default CPU Speed	8.000 MHz
Interrupts	None
System Timer	None
Serial Default	38400 Baud
Memory Manager	MBC
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- PKD: IO=96
- DSRTC: MODE=STD, IO=112
- UART: MODE=SBC, IO=104
- UART: MODE=DUAL, IO=128
- UART: MODE=DUAL, IO=136
- SIO MODE=ZP, IO=176, CHANNEL A
- SIO MODE=ZP, IO=176, CHANNEL B
- PIO: IO=184, CHANNEL A
- PIO: IO=184, CHANNEL B
- PIO: IO=188, CHANNEL A
- PIO: IO=188, CHANNEL B
- LPT: MODE=SPP, IO=232
- CVDU: MODE=MBC, IO=224, KBD MODE=PS/2, KBD IO=226
- TMS: MODE=MBC, IO=152
- KBD: ENABLED
- ESP: IO=156
- ESPCON: ENABLED
- ESPSER: DEVICE=0
- ESPSER: DEVICE=1
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=MBC, IO=48, DRIVE 0, TYPE=3.5" HD
- FD: MODE=MBC, IO=48, DRIVE 1, TYPE=3.5" HD
- PPIDE: IO=96, MASTER
- PPIDE: IO=96, SLAVE
- SPK: IO=112

- CTC: IO=176

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.22 Rhyophyre Z180 SBC

ROM Image File: RPH_std.rom

Default CPU Speed	18.432 MHz
Interrupts	None
System Timer	None
Serial Default	38400 Baud
Memory Manager	RPH
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=132
- ASCI: IO=64
- ASCI: IO=65
- GDC: MODE=RPH, DISPLAY=EGA, IO=144
- KBD: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- PPIDE: IO=136, MASTER
- PPIDE: IO=136, SLAVE

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.23 Z80 ZRC CPU Module

ROM Image File: RCZ80_zrc_std.rom

Default CPU Speed	14.745 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	ZRC
ROM Size	512 KB
RAM Size	1536 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136

Notes:

- ZRC is actually contains no ROM and 2MB of RAM. The first 512KB of RAM is loaded from disk and then handled like ROM.
- CPU speed will be dynamically measured at startup if DSRTC is present

ROM Image File: RCZ80_zrc_ram_std.rom

Default CPU Speed	14.745 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	ZRC
ROM Size	0 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136

Notes:

- ROMless boot – HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

2.24 Z80 ZRC512 CPU Module

ROM Image File: RCZ80_zrc512_std.rom

Default CPU Speed	22.000 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	ZRC
ROM Size	0 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136

Notes:

- ROMless boot – HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

2.25 Z80 EaZy80-512 CPU Module

ROM Image File: RCZ80_ez512_std.rom

Default CPU Speed	22.000 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	115200 Baud
Memory Manager	EZ512
ROM Size	0 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- LCD: IO=218, SIZE=20X4
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=STD, IO=8, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=8, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=EZ512, IO=2, UNITS=1
- KIO: IO=0
- CTC: IO=4, TIMER MODE=TIMER/16, DIVISOR=4608, HI=256, LO=18, INTERRUPTS ENABLED

Notes:

- HBIOS is loaded from disk at boot by ROM monitor
- CPU speed will be dynamically measured at startup if DSRTC is present

2.26 Z80 K80W CPU Module

ROM Image File: RCZ80_k8w_std.rom

Default CPU Speed	22.000 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- LCD: IO=218, SIZE=20X4
- DSRTC: MODE=K80W, IO=192
- UART: IO=128
- UART: IO=136
- UART: IO=160
- UART: IO=168
- SIO MODE=STD, IO=136, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=136, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=EZ512, IO=130, UNITS=1
- KIO: IO=128
- CTC: IO=132, TIMER MODE=TIMER/16, DIVISOR=9216, HI=256, LO=36, INTERRUPTS ENABLED

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.27 Z180 Z1RCC CPU Module

ROM Image File: RCZ180_z1rcc_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	0 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- ROMless boot – HBIOS is loaded from disk at boot

- CPU speed will be dynamically measured at startup if DSRTC is present

2.28 Z280 ZZRCC CPU Module

ROM Image File: RCZ280_zzrcc_std.rom

Default CPU Speed	14.745 MHz
Interrupts	Mode 3
System Timer	Z280
Serial Default	115200 Baud
Memory Manager	Z280
ROM Size	256 KB
RAM Size	256 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- Z2U: IO=16, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- ZZRCC actually contains no ROM and 512KB of RAM. The first 256KB of RAM is loaded from disk and then handled like ROM.
- CPU speed will be dynamically measured at startup if DSRTC is present

ROM Image File: RCZ280_zzrcc_ram_std.rom

Default CPU Speed	14.745 MHz
Interrupts	Mode 3
System Timer	Z280
Serial Default	115200 Baud
Memory Manager	Z280
ROM Size	0 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- Z2U: IO=16, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- ROMless boot – HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

2.29 Z280 ZZ80MB SBC

ROM Image File: RCZ280_zz80mb_std.rom

Default CPU Speed	12.000 MHz
Interrupts	Mode 3
System Timer	Z280
Serial Default	115200 Baud
Memory Manager	Z280
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- Z2U: IO=16, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.30 Z80-Retro SBC

ROM Image File: Z80RETRO_std.rom

Default CPU Speed	14.745 MHz
Interrupts	Mode 2
System Timer	None
Serial Default	38400 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- SIO MODE=Z80R, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=Z80R, IO=128, CHANNEL B, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- SD: MODE=, IO=104, UNITS=1
- CTC: IO=64

Notes:

2.31 S100 Computers Z180

ROM Image File: S100_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	57600 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- SCON: IO=0
- MD: TYPE=RAM
- MD: TYPE=ROM
- SD: MODE=SC, IO=12, UNITS=1

Notes:

- Z180 SBC SW2 (IOBYTE) Dip Switches:

Bit	Setting	Function
0	Off	Use Z180 ASCI Channel A for console
	On	Use Propeller Console
1	Off	Boot to RomWBW Boot Loader
	On	Boot to S100 Monitor

2.32 Duodyne Z80 System

ROM Image File: DUO_std.rom

Default CPU Speed	8.000 MHz
Interrupts	Mode 2
System Timer	CTC
Serial Default	38400 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=148
- PCF: IO=86
- UART: MODE=SBC, IO=88
- UART: MODE=AUX, IO=168
- UART: MODE=DUAL, IO=112
- UART: MODE=DUAL, IO=120
- SIO MODE=ZP, IO=96, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=ZP, IO=96, CHANNEL B, INTERRUPTS ENABLED
- PIO: IO=104, CHANNEL A
- PIO: IO=104, CHANNEL B
- PIO: IO=108, CHANNEL A
- PIO: IO=108, CHANNEL B
- LPT: MODE=SPP, IO=72
- TMS: MODE=MBC, IO=160
- DMA: MODE=DUO, IO=64
- CH: IO=78
- CHUSB: IO=78
- CHSD: IO=78
- ESP: IO=156
- ESPCON: ENABLED
- ESPSER: DEVICE=0
- ESPSER: DEVICE=1
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=DUO, IO=128, DRIVE 0, TYPE=3.5" HD
- FD: MODE=DUO, IO=128, DRIVE 1, TYPE=3.5" HD

- PPIDE: IO=136, MASTER
- PPIDE: IO=136, SLAVE
- SD: MODE=, IO=140, UNITS=1
- SPK: IO=148
- CTC: IO=96, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED
- AY38910: MODE=DUO, IO=164, CLOCK=1789772 HZ

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.33 Heath H8 Z80 System

ROM Image File: HEATH_std.rom

Default CPU Speed	7.372 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=192
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- CTC: IO=136

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

2.34 EP Mini-ITX Z180

ROM Image File: EPITX_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: MODE=RC, IO=160
- UART: MODE=RC, IO=168
- TMS: MODE=MSX, IO=152
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=EPFDC, IO=72, DRIVE 0, TYPE=3.5" HD
- FD: MODE=EPFDC, IO=72, DRIVE 1, TYPE=3.5" HD
- SD: MODE=, IO=66, UNITS=1

Notes:

2.35 NABU w/ RomWBW Option Board

ROM Image File: NABU_std.rom

Default CPU Speed	3.580 MHz
Interrupts	Mode 1
System Timer	None
Serial Default	115200 Baud
Memory Manager	Z2
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- UART: MODE=NABU, IO=72
- TMS: MODE=NABU, IO=160
- MD: TYPE=RAM
- MD: TYPE=ROM
- PPIDE: IO=96, MASTER
- PPIDE: IO=96, SLAVE
- AY38910: MODE=NABU, IO=65, CLOCK=1789772 HZ

Notes:

- TMS video assumes F18A replacement for TMS9918

2.36 S100 FPGA Z80

ROM Image File: FZ80_std.rom

Default CPU Speed	8.000 MHz
Interrupts	None
System Timer	None
Serial Default	9600 Baud
Memory Manager	Z2
ROM Size	0 KB
RAM Size	512 KB

Supported Hardware

- FP: LEDIO=255
- SSER: IO=52
- SCON: IO=0
- MD: TYPE=RAM
- PPIDE: IO=48, MASTER
- PPIDE: IO=48, SLAVE
- FP: LEDIO=255
- DS5RTC: RTCIO=104, IO=104
- SSER: IO=52
- SCON: IO=0
- MD: TYPE=RAM
- PPIDE: IO=48, MASTER
- PPIDE: IO=48, SLAVE
- SD: MODE=FZ80, IO=108, UNITS=2

Notes:

- Requires matching FPGA code

2.37 Genesis STD Z180

ROM Image File: GMZ180_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2

System Timer	Z180
Serial Default	115200 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

Supported Hardware

- DSRTC: MODE=STD, IO=132
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- IDE: MODE=GIDE, IO=32, MASTER
- IDE: MODE=GIDE, IO=32, SLAVE
- SD: MODE=GM, IO=132, UNITS=1

Notes:

- CPU speed will be dynamically measured at startup if DSRTC is present

Chapter 3

Device Drivers

This section briefly describes each of the possible devices that may be discovered by RomWBW in your system.

3.1 Character

ID	Description
ACIA	MC68B50 Asynchronous Communications Interface Adapter
ASCI	Zilog Z180 CPU Built-in Serial Ports
DUART	SCC2681 or compatible Dual UART
ESPCON	ESP32 Firmware-based Video Console
ESPSE	ESP32 Firmware-based Serial Interface
EZ80UART	eZ80 Serial Interface
LPT	Parallel I/O Controller
PIO	Zilog Parallel Interface Controller
PPPCON	ParPortProp Serial Console Interface
PRPCON	PropIO Serial Console Interface
SCON	S100 Console
SIO	Zilog Serial Port Interface
SSER	Simple Serial Interface
UART	16C550 Family Serial Interface
USB-FIFO	FT232H-based ECB USB FIFO
Z2U	Zilog Z280 CPU Built-in Serial Ports

By default, RomWBW will use the first available character device it discovers for the initial

console. The following character devices are scanned in the order shown. The available character devices depend on the active platform and configuration.

1. SSER: Simple Serial Interface
2. ASCI: Zilog Z180 CPU Built-in Serial Ports
3. Z2U: Zilog Z280 CPU Built-in Serial Ports
4. UART: 16C550 Family Serial Interface
5. DUART: SCC2681 or compatible Dual UART
6. SIO: Zilog Serial Port Interface
7. EZ80UART: eZ80 Serial Port Interface
8. ACIA: MC68B50 Asynchronous Communications Interface Adapter
9. USB-FIFO: FT232H-based ECB USB FIFO

3.2 Disk

ID	Description
CHSD	CH37x SD Card Interface
CHUSB	CH37x USB Drive Interface
FD	8272 or compatible Floppy Disk Controller
HDSK	SIMH Simulator Hard Disk
IDE	IDE/ATA/ATAPI Hard Disk Interface
IMM	Zip Drive on PPI (IMM variant)
MD	ROM/RAM Disk
PPA	Zip Drive on PPI (PPA variant)
PPIDE	8255 IDE/ATA/ATAPI Hard Disk Interface
PPPSD	ParPortProp SD Card Interface
PRPSD	PropIO SD Card Interface
RF	RAM Floppy Disk Interface
SD	SD Card Interface
SYQ	Iomega SparQ Drive on PPI

3.3 Video

ID	Description
CVDU	MC8563-based Video Display Controller
EF	EF9345 Video Display Controller
FV	S100 FPGA Z80 Onboard VGA/Keyboard

ID	Description
GDC	uPD7220 Video Display Controller
TMS	TMS9918/38/58 Video Display Controller
VDU	MC6845 Family Video Display Controller
VGA	HD6445CP4-based Video Display Controller
VRC	VGARC Video Display Controller

3.4 Keyboard

ID	Description
KBD	8242 PS/2 Keyboard Controller
MSXKYB	MSX Compliant Matrix Keyboard
NABUKB	NABU Keyboard
PPK	Matrix Keyboard

3.5 Audio

ID	Description
AY	AY-3-8910/YM2149 Programmable Sound Generator
SN76489	SN76489 Programmable Sound Generator
SPK	Bit-bang Speaker
YM	YM2612 Programmable Sound Generator

3.6 RTC (RealTime Clock)

ID	Description
BQRTC	BQ4845P Real Time Clock
DS5RTC	Maxim DS1305 SPI Real-Time Clock w/ NVRAM
DS7RTC	Maxim DS1307 PCF I2C Real-Time Clock w/ NVRAM
DS1501RTC	Maxim DS1501/DS1511 Watchdog Real-Time Clock
DSRTC	Maxim DS1302 Real-Time Clock w/ NVRAM
EZ80RTC	eZ80 Real-Time Clock
INTRTC	Interrupt-based Real Time Clock

ID	Description
PCF	PCF8584-based I2C Real-Time Clock
RP5C01	Ricoh RPC01A Real-Time Clock w/ NVRAM
SIMRTC	SIMH Simulator Real-Time Clock

3.7 DsKy (DiSplay KeYpad)

ID	Description
FP	Simple LED & Switch Front Panel
GM7303	Prolog 7303 derived Display/Keypad
H8P	Heath H8 Display/Keypad
ICM	ICM7218-based Display/Keypad on PPI
LCD	Hitachi HD44780-based LCD Display
PKD	P8279-based Display/Keypad on PPI

3.8 System

ID	Description
CH	CH375/376 USB Interface Controller
CTC	Zilog Clock/Timer
DMA	Zilog DMA Controller
ESP	ESP32 Firmware-based interface
EZ80TIMER	eZ80 System Timer
KIO	Zilog Serial/ Parallel Counter/Timer
PPP	ParPortProp Host Interface Controller
PRP	PropIO Host Interface Controller

Chapter 4

UNA Hardware BIOS

John Coffman has produced a new generation of hardware BIOS called UNA. The standard RomWBW distribution includes its own hardware BIOS. However, RomWBW can alternatively be constructed with UNA as the hardware BIOS portion of the ROM. If you wish to use the UNA variant of RomWBW, then just program your ROM with the ROM image called “UNA_std.rom” in the Binary directory. This one image is suitable on **all** of the platforms and hardware UNA supports.

UNA is customized dynamically using a ROM based setup routine and the setup is persisted in the system NVRAM of the RTC chip. This means that the single UNA-based ROM image can be used on most of the RetroBrew platforms and is easily customized. UNA also supports FAT file system access that can be used for in-situ ROM programming and loading system images.

While John is likely to enhance UNA over time, there are currently a few things that UNA does not support:

- Floppy Drives
- Terminal Emulation
- Zeta 1, N8, RCBUS, Easy Z80, and Dyno Systems
- Some older support boards

The UNA version embedded in RomWBW is the latest production release of UNA. RomWBW will be updated with John’s upcoming UNA release with support for VGA3 as soon as it reaches production status.

Please refer to the [UNA BIOS Firmware Page](#) for more information on UNA.

4.1 UNA Usage Notes

- At startup, UNA will display a prompt similar to this:

Boot UNA unit number or ROM? [R,X,0..3] (R):

You generally want to choose 'R' which will then launch the RomWBW loader. Attempting to boot from a disk using a number at the UNA prompt will only work for the legacy (hd512) disk format. However, if you go to the RomWBW loader, you will be able to perform a disk boot on either disk format.

- The disk images created and distributed with RomWBW do not have the correct system track code for UNA. In order to boot to disk under UNA, you must first use SYSCOPY to update the system track of the target disk. The UNA ROM disk has the correct system track files for UNA: CPM.SYS and ZSYS.SYS. So, you can boot a ROM OS and then use one of these files to update the system track.
- The only operating systems supported at this time are CP/M 2 and ZSDOS. NZ-COM is also supported because it uses the ZSDOS CBIOS. None of the other RomWBW operating systems are supported such as CP/M 3, ZPM3, and p-System.
- Some of the RomWBW-specific applications are not UNA compatible.

Chapter 5

Errata

The following errata apply to RomWBW Version 3.5:

- The use of high density floppy disks requires a CPU speed of 8 MHz or greater.
- The PropIO support is based on RomWBW specific firmware. Be sure to program/update your PropIO firmware with the corresponding firmware image provided in the Binary directory of the RomWBW distribution.
- Reading bytes from the video memory of the VDU board (not Color VDU) appears to be problematic. This is only an issue when the driver needs to scroll a portion of the screen which is done by applications such as WordStar or ZDE. You are likely to see screen corruption in this case.
- The RomWBW TUNE application will detect an AY-3-8910/YM2149 Sound Module regardless of whether support for it is included in the RomWBW HBIOS configuration.