



# **IMPORTANT**


## **PROCEDURES FOR LOW LUBE & 3CN FIFTH WHEELS**

1. ADJUST THE TRAILER HEIGHT SO THE FIFTH WHEEL SLIDES FREELY UNDER THE TRAILER.

### **DO NOT LIFT THE TRAILER WITH THE FIFTH WHEEL**

THIS COULD RESULT IN DAMAGE OR PERSONAL INJURY!

2. THE FRONT EDGE OF THE TRAILER UPPER COUPLER MUST HAVE A RADIUS OR A CHAMFER (SEE FIGURE 1).



**FIGURE 1**

3. IF POSSIBLE KEEP THE LOW LUBE PLATES FROM EXTENDED SUNLIGHT EXPOSURE AT ELEVATED TEMPERATURES.  
MAY CAUSE LUBE PLATES TO EXPAND AND PUCKER BETWEEN BOLTS