

Optional power supply jumper
(if not powering from backplane)

Power/filtering/monitor


TITLE: Eurocard-HU-piezo-driver

Document Number:



REV:

Date: 9/13/16 8:26 PM

Sheet: 3/5



Digital/ucontroller	
TITLE: Eurocard-HV-piezo-driver	
Document Number:	REV:
Date: 9/13/16 8:26 PM	Sheet: 4/5



Extra parts

53404-ND (jumper)

UMC button for optional connection via frontpanel

Backplane signal/power	
TITLE: Eurocard-HV-piezo-driver	
Document Number:	REV:
Date: 9/13/16 8:26 PM	Sheet: 5/5