

Sheet: /Motor Control/
File: MotorControl.kicad_sch

Title:



Size: A4

Date:

KiCad E.D.A. 9.0.4

Rev:

Id: 2/6



Sheet: /Power/
File: Power.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 9.0.4

Rev:

Id: 5/6



Sheet: /Sensing/
File: Sensing.kicad_sch

Title:

Size: A4


Date:

KiCad E.D.A. 9.0.4


Rev:

Id: 6/6

Screen Drivers




Buttons



NOTE: This will cause LED buttons to only register presses when LED is on.
The plan is flashing right? Either the circuit must change or need
constant LED lighting to double as button enable. If circuit change,
split GNDs such that only LED GND goes through mosfet

Speakers



Sheet: /HMI_No_Raspi/
File: HMI_No_Raspi.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 9.0.4

Rev:

Id: 7/6