

## 35MM Fast-Fit device

### Standard creasing inserts

#### **2x Orange Gripper Crease (M-163):**

used to crease material weight between 100-200gsm

#### **2x Blue Gripper Crease (M-162):**

used to crease material weight between  
200-270gsm

#### **2x Yellow Gripper Crease (M-161):**

used to crease material weight between  
250-350gsm

**The B version inserts will stop any front edge damage but the B version inserts will not go as deep as the standard inserts. (Front edge damage only happens on rare occasions. We recommend the standard inserts for your customers.**

### Optional B version inserts

#### **2x Orange Gripper Crease (M-163B):**

Used to crease material weight between 100-180gsm

If fibre cracking is not a problem the deep and penetrating nylon ribs are ideal for laminated and section work

#### **2x Blue Gripper Crease (M-162B):**

Used to crease material weight between  
180-200gsm

FF-PC/35-R    **red** light crease

FF-PC/35-B    **blue** medium crease

#### **2x Yellow Gripper Crease (M-161B):**

crease material weight between 300-350gsm

FF-PC/35-Y    **yellow** heavy crease

FF-PC/35-BLK    **black** extra heavy crease

#### **2x Yellow Gripper Crease (M-164B):**

Used to crease material weight between  
350-400gsm