

ARMABOT

Pnexapod

P/N A0047

Installation
Instructions

Slip guide plate
over ball joints.

Attach ball joints to
main plate (6x per
plate, 2 plates)

For top plate,
nut goes inside
clevis fork.

Attach
cylinders to
ball joints.

