

Part No.	PWN2009A-B	ADDED WND 2		CYCLE TIMES		Thru-Put/8Hrs	3368	Wgt/Pc.		Mach No.	S4
Order No.	388008	Standard		Planned Pcs/Hr		421	Wgt/Bar		Setup Allowed Hrs.	4	
Order Qty	2000	3500	10/28	Actual		Actual Pcs/Hr		Component	A02061-0012	Pcs./Bar	
Date	Emp. Name	Prod. Hours	Total Pcs	Cum. Total	Material Heat Lot No.	Down Time	Down Time Code	Notes	Scrap Pcs.	Scrap Code	
11/11	MATT	15	225	225		4	3	Flight Hardware	45	11	
11/11	ED	6	2270	2495		2	2				
11/11	DM	2.5	1325	3820		2	2				
<p>NO PARTS @ Machine</p> <p>JOB OUT</p> <p>410.00/15</p>											
TOTAL PCS. PRODUCED											
TOTAL SCRAP PCS.											
<p>Special Notes / Instructions</p> <p>FOR DAVENPORTS & BROWN & SHARPS ONLY: To Figure Pieces From Loads = Pcs/Bar x Total loads ran during shift x Bars per load</p>											
<p>First Part Inspection Record</p> <p>Date Part Submitted</p> <p>Time of Day</p> <p>Approved Yes/No</p> <p>Mtrl Check</p> <p>Rev Letter</p> <p>Inspector</p> <p>Notes</p>											