



FLAT ROCK TRANSITION (FAK.COATT4): From over FAK VORTAC via FAK R-031 to COATT INT. Thence

RICHMOND TRANSITION (RIC.COATT4): From over RIC VORTAC via RIC R-345 to COATT INT. Thence

. . . . From over COATT INT via FAK R-031 to BRV VORTAC, then from over BRV VORTAC via BRV R-007 to BARIN INT. Expect radar vectors to final approach course after BARIN INT.