


Thermoelectric Optimizer – SPB Model App

Dr. Jan-Hendrik Pöhls

July 2020

Montreal QC Canada


$$\Phi^2 \pi$$




Introduction

Welcome to the Thermoelectric Optimizer App.

The App is based on the single-parabolic band model and can compute using empirical parameters such as Seebeck coefficient and mobility:


- Electrical thermal conductivity
- Seebeck coefficient, mobility, Lorenz number, and thermoelectric figure of merit as function of the charge carrier concentration
- Thermoelectric figure of merit as function of charge carrier concentration and temperature
- Optimized charge carrier concentration and thermoelectric figure of merit as function of temperature versus experimental data




Introduction

- SPB model assumes that the effective mass does not change with carrier concentration (i.e., single parabolic band) and that the electron transport is limited by a single scattering mechanism:
 - Acoustic Deformation Potential (ADP) → vibrations of atoms reduce the mobility of the charge carriers
 - Polar Optical Phonon (POP) → charge carriers are scattered of the electric field of polar atoms (**material needs to be hetero-polar**)
- or
- Ionized Impurity (IMP) → charge carriers are scattered by the ionization of the lattice (i.e., unbalanced local charge near a crystal impurity)

Installation




- Download all files (i.e., Thermoelectric Optimizer.py), the example .csv file (i.e. Example_SPB.csv) , and the icon (i.e., icon_spb.ico)
- Create a new folder and move all files in the folder (please note that temporary files will be save in the folder as well)
- Please note that the App won't work if the icon is not in the same folder than the python file (.csv file can be in a different folder)



Starting the program

- If you haven't download a Python 3.xx, please download it
 - Make sure that these packages are available:
 - tkinter, os, json, numpy, scipy, and matplotlib
- Open the App using command line: `python Thermoelectric Optimizer.py`
- The opening of the App takes some time depending on your processor

Start Window – Input Parameters





Input parameters from experiments

- A : Compound name (required)**
- B : Temperature in K (required)**
(Temperature should be above 1 and below 10,000 K)
- C : Seebeck Coefficient in $\mu\text{V K}^{-1}$ (required; only positive values)**
(Seebeck coefficient should be above 0.1 and below 1,500 $\mu\text{V K}^{-1}$)
- D : Carrier Concentration in cm^{-3} (not required; only positive values)**
(Carrier Concentration should be above 1E12 and below 1E24 cm^{-3})
- E : Mobility in $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$ (not required)**
(Mobility should be above 0.01 and below 10,000 $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$)
- F : Total thermal Conductivity in $\text{W m}^{-1} \text{K}^{-1}$ (not required)**
(Thermal Conductivity should be above 0 and below 10,000 $\text{W m}^{-1} \text{K}^{-1}$)
- G : Dielectric Constant (unitless) (not required)**
(Dielectric Constant should be above 1 and below 100,000)

Red is required to press 'Calculate' and 'Plot'. Green is not required.; only to compute certain parameters

* (req.) means required

Start Window – Calculation




H : Choose the scattering mechanism (5)


- **Acoustic Deformation Potential**
- **Polar Optical Phonon**
- **Ionized Impurity**
 - **Brooks-Herring (with screening)**
 - **Requires Dielectric Constant**
 - **Takes a long time which increases with increasing Seebeck Coefficient**
- **Polar Optical Phonon (Fermi)**
 - **Slight overestimation at high Carrier Concentration**
- **Ionized Impurity (Fermi)**
 - **Conwell-Weisskopf (without screening)**
 - **No Dielectric Constant required**
 - **Fast**
 - **Overestimation at high Carrier Concentration**

I : Calculate the properties below (make sure required fields have a value)

Start Window – Output Parameters



NaN (not a number) is the default and only change if the parameter is computed



J : Chemical Potential in meV (Computed from the Seebeck coefficient) *

K : Effective mass in m_e (Computed from the Seebeck coefficient and Carrier Concentration)

L : Intrinsic Mobility in $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$ (Computed from the Seebeck coefficient, Carrier Concentration and Mobility)

M : Lorenz number in $\text{W } \Omega \text{ K}^{-2}$ (Computed from the Seebeck coefficient) *



N : Electronic Thermal Conductivity in $\text{W m}^{-1} \text{K}^{-1}$ (Computed from the Seebeck coefficient, Carrier Concentration, and Mobility)

O : Lattice Thermal Conductivity in $\text{W m}^{-1} \text{K}^{-1}$ (Computed from the Seebeck coefficient, Carrier Concentration, Mobility, and Thermal Conductivity)

P : Thermoelectric Figure of Merit, zT (Computed from the Seebeck coefficient, Carrier Concentration, Mobility, and Thermal Conductivity)

* except Brooks-Herring Ionized Impurity Scattering which also requires Carrier Concentration and Dielectric Constant

Start Window – Save Information





Q : Extension of File to save the above properties

- **.csv (Comma delimited file) → Can be open with Excel**
- **.json (Json file) → Can be open with Python**

R : Save Button

When the button ‘Calculate’ is pressed, a temporary file is produced and saved in the App folder. The information of the temporary file is used for the file to save to avoid that you change accidentally the input parameters and save the incorrect input parameters with the calculated parameters.

Start Window – Plot Information



Carrier Concentration Range

S : Minimum Carrier Concentration in cm^{-3}
(required; only positive values)

(Carrier Concentration should be above $1\text{E}12$ and below $1\text{E}24 \text{ cm}^{-3}$)

T : Maximum Carrier Concentration in cm^{-3}
(required; only positive values)

(Carrier Concentration should be above $1\text{E}12$ and below $1\text{E}24 \text{ cm}^{-3}$ and should be higher than minimum Carrier Concentration)

U : Plot button (Input parameters are required)
Create temporary file for the plot data



V : Plot Data on y-axis *

- Seebeck Coefficient (requires A, B, C, S, and T)
- Mobility (requires A, B, C, D, E, S, and T)
- Lorenz number (requires A, B, C, S, and T)
- Thermoelectric Figure of Merit (requires A, B, C, D, E, F, S, and T)

*** except Brooks-Herring Ionized Impurity Scattering which also requires Carrier Concentration and Dielectric Constant**

W : Save Button (save data of the plot with the extension which is set in R)

Start Window



X : Plot

Y : (from left to right)

House : Original Plot

Arrow left : Go to last step (if you zoomed in)

Arrow right : Go one step forward (if you went back)

Cross : Left-click → move graph



Right-click → zoom in

Magnifying glass : Zoom in

Shifters : No effect

Disk : Save the plot

File Menu



A1 : New

- Remove all temporary files
- Clean Plot
- Remove all data


B1: Open File

- Open .csv file (see next slide)

C1: Exit

- Close the App
- Remove all temporary files

Open File



Seebeck Coefficient
in $\mu\text{V K}^{-1}$ \rightarrow needs to
be positive

Carrier Concentration
in cm^{-3} \rightarrow needs to be
positive

Thermal Conductivity
in $\text{W m}^{-1} \text{K}^{-1}$

Compound
Name

Temperature
in K



Mobility in
 $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$

Dielectric Constant

Example CSV file
(It needs to be in
this order and no
empty rows; empty
values are fine but
you need at least
a name, temperature
and Seebeck
coefficient for each
row; marked in red)

	A	B	C	D	E	F	G	H	I
1	Compound	Temperature / K	Seebeck Coefficient / $\mu\text{V K}^{-1}$	Carrier Concentration / cm^{-3}	Mobility / $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$	Thermal Conductivity / $\text{W m}^{-1} \text{K}^{-1}$	Dielectric Constant		
2	A1	300	140	$3.00\text{E}+19$	80	3.4	200		
3	A1	400	180	$3.60\text{E}+19$	60	2.7	200		
4	A1	600	220	$3.90\text{E}+19$	34	2.1	200		
5	B1	450	35	$3.00\text{E}+21$	10	12	10		
6	C1	303	98	$1.00\text{E}+20$	112	5	80		
7	C1	403	145	$2.00\text{E}+20$	97	4.6	80		
8	C1	503	200	$2.20\text{E}+20$	87	4.3	80		
9									
10									
11									
12									
13									
14									
15									
16									
17									
18									
19									
20									
21									

Uploaded Data





A* : List of Compound names
B* : List of Temperatures for the Corresponding Compound

Changing the compound will update the temperature list and the Seebeck Coefficient, Carrier Concentration, Mobility, Thermal Conductivity and Dielectric Constant

(The same for changing the temperature)

Edit Menu




A2 : Edit Graph

- Edit the graph on the first window and optimized graphs (see later)
- Other font, font size, or reposition it

B2 : Edit Graph 3D

- Edit the graph for the 3D plot
- Other font, font size, or change the surface to a 3D grid

Edit Graph



Thermoelectric Optimizer - SPB Model App

Font Size	16 A_Graph	Figure Width	8 C_Graph
Font B_Graph	Times New Roman	Figure Height	4.3 D_Graph
Plot Start x	0.18 E_Graph	Plot Width x	0.78 F_Graph
Plot Start y	0.23 G_Graph	Plot Width y	0.68 H_Graph
<input type="button" value="Close"/>			

Close the
window
(produce an
empty graph)

A_Graph : Font Size

B_Graph : Font (Choose Times New Roman or Arial) *

C_Graph : Width of the figure

D_Graph : Height of the figure

E_Graph : x-point where the plot starts in the figure



F_Graph : Width of the plot

G_Graph : y-point where the plot starts in the figure

H_Graph : Height of the plot

*** For more fonts, please send me an email**

Edit Graph 3D



Close the
Window

A_3D_Graph : Font Size

B_3D_Graph : Font (Choose Times New Roman or Arial) *



C_3D_Graph : Width of the 3D figure

D_3D_Graph : Height of the 3D figure

E_3D_Graph : Change between a surface or wired 3D Figure



Surface:

Wired:



* For more fonts, please send me an email

Compute Menu



A3 : Compute All (enabled when a file was open)

- Compute all the properties of a .csv file
- If Minimum and Maximum Carrier Concentration are given, compute all the properties as a function of Carrier Concentration
- Save computed data in a folder → each compound/temperature pair has its own safe file

B3 : Compute Optimize Carrier Concentration

- Compute the Thermolectric Figure of Merit as a function of Carrier Concentration and Temperature
- Compute Optimized Carrier Concentration and the corresponding Optimized Thermolectric Figure of Merit

Compute Optimized Carrier Concentration

Thermoelectric Optimizer - SPB Model App

Provide polynomial fitting coefficients of all thermoelectric parameters

Seebeck Coefficient Coefficients / $\mu\text{V K}^{-1}$	1	A_Opt	* T^0
Carrier Concentrations Coefficients / cm^{-3}	1	B_Opt	* T^0
Mobility Coefficients / $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$	1	C_Opt	* T^0
Thermal Conductivity Coefficients / $\text{W m}^{-1} \text{K}^{-1}$	1	D_Opt	* T^0

Temperature range / K

Min. T Max. T Step T

Carrier Concentration range / cm^{-3}

Min. n Max. n

Acoustic Deformation Potential

☐ 3D plot ☐ Exp. Plot ☐ Opt. Plot **Plot** .csv **Save** **Close Window**

A_Opt: Temperature-dependent Seebeck Coefficient in $\mu\text{V K}^{-1}$ described by polynomial to the fifth order

For example: $S = 100 * T^0 + 0.8 * T^1 + -1\text{E-}5 * T^2 \rightarrow$ Change List to 3 and write 100, 0.8, and -1E-5 in the three fields

B_Opt: Temperature-dependent Carrier Concentration cm^{-3} described by polynomial to the fifth order

C_Opt: Temperature-dependent Mobility in $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$ described by polynomial to the fifth order

D_Opt: Temperature-dependent Thermal Conductivity in $\text{W m}^{-1} \text{K}^{-1}$ described by polynomial to the fifth order

Compute Optimized Carrier Concentration

Thermoelectric Optimizer - SPB Model App

Provide polynomial fitting coefficients of all thermoelectric parameters

Seebeck Coefficient Coefficients / $\mu\text{V K}^{-1}$	1		* T^0
Carrier Concentrations Coefficients / cm^{-3}	1		* T^0
Mobility Coefficients / $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$	1		* T^0
Thermal Conductivity Coefficients / $\text{W m}^{-1} \text{K}^{-1}$	1		* T^0
Temperature range / K	Min. T	E_Opt	Max. T F_Opt Step T G_Opt
Carrier Concentration range / cm^{-3}	Min. n	H_Opt	Max. n I_Opt

Acoustic Deformation Potential ☐ ☐ 3D plot ☐ Exp. Plot ☐ Opt. Plot **Plot** .csv ☐ **Save** Close Window

E_Opt: Minimum Temperature in K (above 1 and below 10,000 K)

F_Opt: Maximum Temperature in K (above 1 and below 10,000 K and above Minimum Temperature)

G_Opt: Temperature Step in K (above 1 and below 100 K)

H_Opt: Temperature-dependent Thermal Conductivity in $\text{W m}^{-1} \text{K}^{-1}$ described by polynomial to the fifth order

Compute Optimized Carrier Concentration

Thermoelectric Optimizer - SPB Model App

Provide polynomial fitting coefficients of all thermoelectric parameters

Seebeck Coefficient Coefficients / $\mu\text{V K}^{-1}$	1		$\times T^0$			
Carrier Concentrations Coefficients / cm^{-3}	1		$\times T^0$			
Mobility Coefficients / $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$	1		$\times T^0$			
Thermal Conductivity Coefficients / $\text{W m}^{-1} \text{K}^{-1}$	1		$\times T^0$			
Temperature range / K	Min. T		Max. T		Step T	
Carrier Concentration range / cm^{-3}	Min. n		Max. n			

J_Opt **K_Opt** **L_Opt** **M_Opt**

Acoustic Deformation Potential ☐ 3D plot ☐ Exp. Plot ☐ Opt. Plot **Plot** .csv **Save** **Close Window**

J_Opt: Choose the scattering mechanism (5)

- Acoustic Deformation Potential
- Polar Optical Phonon
- Ionized Impurity
- Polar Optical Phonon (Fermi)
- Ionized Impurity (Fermi)

K_Opt: Create a 3D plot (Temperature, Carrier Concentration and Thermoelectric Figure of Merit)

L_Opt: Create experimental Carrier Concentration vs Temperature and experimental Thermoelectric Figure of Merit vs Temperature

M_Opt: Create optimized Carrier Concentration vs Temperature and optimized Thermoelectric Figure of Merit vs Temperature

(If both are clicked, the experimental Carrier Concentration and Thermoelectric Figure of Merit are compared to the optimized values)

Compute Optimized Carrier Concentration

Thermoelectric Optimizer - SPB Model App

Provide polynomial fitting coefficients of all thermoelectric parameters

Seebeck Coefficient Coefficients / $\mu\text{V K}^{-1}$ * T^0

Carrier Concentrations Coefficients / cm^{-3} * T^0

Mobility Coefficients / $\text{cm}^2 \text{V}^{-1} \text{s}^{-1}$ * T^0

Thermal Conductivity Coefficients / $\text{W m}^{-1} \text{K}^{-1}$ * T^0

Temperature range / K Min. T Max. T Step T

Carrier Concentration range / cm^{-3} Min. n Max. n

Acoustic Deformation Potential

☐ 3D plot ☐ Exp. Plot ☐ Opt. Plot

N_Opt **O_Opt** **P_Opt**

Plot .csv Save Close Window

Close the Window

N_Opt : Plot the data for the corresponding plots (K, L, or M)

O_Opt : Choose the format to save the computed data (experimental versus optimized data)


- .csv file (Excel format)
- .json file (Python format)

P_Opt : Save button

Important: If the data is plotted, the main window can decrease (if the App is using in Microsoft Windows).

You can change it by going → Display Settings → Change the size of text, apps, and other items to 100%

Questions?



- If you have questions or concerns or find some errors, please send me an email: Jan.Poehls@Dal.ca
- Thank you for choosing the Thermoelectric Optimizer – SPB Model App