

AS DISCUSSED ON SITE WITH QED, FOLD SHEET METAL BACK TO RECONSTRUCTED CHAMFERED CORNER. ADD 1/4" SEALANT BETWEEN SHEETMETAL AND CONCRETE. STOREFRONT, SHEETMETAL, AND CONCRETE SHOULD ALL ALIGN. SEE REVISED DETAIL BELOW. TYPICAL FOR ALL SIMILAR CONDITIONS.




PHOTO TAKEN ON GROUND FLOOR OF BUILDING B AT BIKE ROOM.