

ALL BATTENS SHOULD HAVE
CLEAN JOINTS. INSTALL
INTERIOR STIFFENER IF
NECESSARY FOR ACCURATE
CONNECTION AND DETAILING.

