



BATTENS SHOULD BE
ALIGNED WITHOUT GAPS.
INSTALL STIFFENERS WITH
A MAX 3/8" EXPANSION
JOINT SIMILAR TO
RECESSED WINDOW
INSTALLATION.

PHOTO TAKEN ON COURTYARD SIDE OF BUILDING C.