

PER THE OWNERS
DIRECTION, INSTALL A
TRANSITION STRIP BETWEEN
BEDROOM CARPET AND LVT.
TYPICAL ALL LOCATIONS ALL
BUILDINGS.

