

PER QED'S DIRECTION,  
FOLD TOP OF METAL  
PANEL BACK AND ADD  
NO BIGGER THAN 1/2"  
SEALANT AND BACKER  
ROD. MAKE  
CONSISTENT WITH  
STOREFRONT.

SEALANT AND  
BACKER ROD  
SHOULD BE NO  
BIGGER THAN 1/2".  
REMOVE AND  
REPLACE.

METAL PANEL TO STOREFRONT MOCK-UP

PHOTO TAKEN ON GROUND FLOOR OF  
BUILDING B NEAR BIKE ROOM.