


Cisco Conference Phone



LED status indicators:

Green, steady: Active call
Green, pulse: Held call
Green, flashing: Incoming call
Red, steady: Remote line in use
Red, pulse: Remote line on hold

Make a Call

Press Call Button and enter 9 + a number.

Answer a Call

Press Call Button to answer a call.

Put a Call on Hold

Press Hold Softkey.
To resume a held call, press Call Button or Resume Softkey.

Mute Your Audio

Press Mute . It will be backlit by a solid red light.
Press Mute again to turn mute off.

Transfer a Call to Another Person

While on an active call press Transfer Softkey.
Enter the other person's phone number.
Wait for the recipient to answer.
Press Transfer again to complete the transfer.

Add Another Person to a Call

From a connected call that is not on hold, press Conference Softkey .
After the party answers, press Conference again.

Adjust the Volume of a Call

Press Volume Rocker left or right to adjust the speakerphone volume when the phone is in use.

Change the Ringtone

Press Applications Softkey .
Use the Navigation bar and Select button to scroll to select Preferences, then select Ringtone.
Select a ringtone.
Press **Set** to select the ringtone.
Press **Apply** to confirm your selection, or press **Cancel** to go back to the Ringtone screen.
Press return arrow to return to the Preferences screen.

Adjust the Screen Contrast

Press Applications Softkey .
Use the Navigation bar and Select button to scroll to select Preferences.
Select **Contrast**.
To increase contrast, press the up arrow on the Navigation bar. To decrease contrast, press the down arrow.
Press **Save** to set the contrast level, or press **Cancel** to exit.